



SMARTSTOR
NS2300N
Product Manual

Version 1.0

Copyright

© 2008 Promise Technology, Inc. All Rights Reserved.

Copyright by Promise Technology, Inc. (Promise Technology). No part of this manual may be reproduced or transmitted in any form without the expressed, written permission of Promise Technology.

Trademarks

Promise, and the Promise logo are registered in U.S. Patent and Trademark Office. All other product names mentioned herein may be trademarks or registered trademarks of their respective companies.

Important data protection information

You should back up all data before installing any drive controller or storage peripheral. Promise Technology is not responsible for any loss of data resulting from the use, disuse or misuse of this or any other Promise Technology product.

Notice

Although Promise Technology has attempted to ensure the accuracy of the content of this manual, it is possible that this document may contain technical inaccuracies, typographical, or other errors. Promise Technology assumes no liability for any error in this publication, and for damages, whether direct, indirect, incidental, consequential or otherwise, that may result from such error, including, but not limited to loss of data or profits.

Promise Technology provides this publication “as is” without warranty of any kind, either express or implied, including, but not limited to implied warranties of merchantability or fitness for a particular purpose.

The published information in the manual is subject to change without notice. Promise Technology reserves the right to make changes in the product design, layout, and driver revisions without notification to its users.

This version of the *Product Manual* supersedes all previous versions.

Recommendations

In this *Product Manual*, the appearance of products made by other companies, including, but not limited to software, servers, and disk drives, is for the purpose of illustration and explanation only. Promise Technology does not recommend, endorse, prefer, or support any product made by another manufacturer.

Contents

Chapter 1: Introduction to SmartStor	1
About This Manual	1
Architecture	2
Protocol Support	2
Key Benefits	2
Specifications	3
Compatible Backup Software	4
Client OS Support	4
Browser Support	4
Chapter 2: Installation and Setup	5
Unpacking the SmartStor NS2300N	5
Installing Disk Drives	7
Connecting to the Network	7
Connecting the Power	7
Installing the Software	8
Setting up the SmartStor	11
Connecting to PASM	15
Browser Support	15
Finding the SmartStor's IP Address	15
PASM in your Browser	16
PASM in SmartNAVI	17
Shutting Down the SmartStor	18
Chapter 3: Connecting to the SmartStor	19
Setting up a Network Drive on a Windows PC	19
Setting up a Network Drive on a UNIX or Linux PC	22
Setting up a Network Drive on a Macintosh PC	26
Connecting a USB Printer to SmartStor	29
Setting up the Print Server on SmartStor	30
Setting up Windows Printing	30
Setting up Linux Printing	32
Setting up Macintosh Printing	35
Connecting a USB Drive	37
Disconnecting a USB Drive	40
Setting-up Apple iTunes	40

Chapter 4: SmartNAVI	45
Working with SmartNAVI	45
Opening SmartNAVI	45
Opening the MSN Window	46
Opening the Main Window	46
Choosing a SmartNAVI Language	47
Starting the Advanced Storage Manager (PASM)	47
Viewing SmartNAVI Information	48
Closing SmartNAVI	49
Managing Users and Groups	50
Creating a User	50
Creating the Default User	51
Changing User Passwords	51
Changing User Permissions	51
Viewing a List of Users	52
Deleting a User	52
Creating a Group	52
Viewing a List of Groups	53
Adding Members to a Group	53
Deleting Members from a Group	53
Deleting a Group	54
Managing RAID Volumes	55
Creating a RAID Volume	55
Expanding a RAID Volume	55
Viewing RAID Volume Status	56
Viewing a List of RAID Volumes	56
Recreating a RAID Volume	57
Managing Backups	58
Doing a Backup Now	58
Scheduling a Backup	59
Viewing Backup Schedules	60
Changing a Scheduled Backup	60
Deleting a Scheduled Backup	61
Restoring Backed-up Files	61
Viewing the Backup Event Log	62
Saving the Event Log	62
Clearing the Event Log	63
Managing Share Folders	64
Creating a Share Folder	64
Opening a Share Folder	64
Viewing a List of Share Folders	65

Chapter 4: SmartNAVI, cont.

Managing Share Folders, cont.	
Changing Share Folder Permissions	65
Deleting a Share Folder	65
Mounting a Share Folder / Creating a Network Drive	66
Un-mounting a Share Folder / Disconnecting a Network Drive	66
Making Management Settings	67
Configuring a NAS System	67
Changing Network Settings	69
Locating the SmartStor	70
Choosing a Default NAS System	70
Enabling or Disabling Event Notification	70
Viewing the System Event Log	71
Adding Plug-ins	71
Viewing a List of Plug-ins	72
Viewing Plug-in Version Numbers	72
Enabling and Disabling Plug-ins	73
Removing Plug-ins	73
Managing Downloads	75
Adding a Link	75
Viewing the Download List	76
Removing a Link	76
Pausing and Resuming a Download	76
Viewing the Downloaded List	77
Opening a Downloaded File	77
Deleting a Downloaded File	77

Chapter 5: PASM **79**

Connecting to PASM	79
PASM in your Browser	80
PASM in SmartNAVI	81
Choosing a Language	82
Navigating in PASM	82
Logging out of PASM	82
Setting up SmartStor with the Setup Wizard	83
Managing Users and Groups	85
Viewing a List of Users	85
Creating a User	85
Changing the Administrator's Password	85
Changing a User's Password	86
Deleting a User	86

Chapter 5: PASM, cont.

Managing Users and Groups, cont.	
Viewing a List of Groups86
Creating a Group87
Adding Members to a Group87
Removing Members from a Group87
Deleting a Group88
Viewing Quotas88
Setting Quotas88
Managing File & Print Services90
Setting up Windows Access90
Setting up UNIX/Linux Access91
Setting up for Macintosh Access92
Setting up for FTP Access93
Setting up your Print Server94
Adding Plug-ins94
Viewing a List of Plug-ins95
Enabling and Disabling Plug-ins95
Removing Plug-ins96
Viewing a List of Folders96
Modifying Folder Services96
Adding a Folder97
Deleting a Folder97
Setting up Windows Sharing for a Folder98
Setting up UNIX and Linux Sharing for a Folder98
Setting up FTP Sharing for a Folder99
Managing RAID Volumes	100
Viewing RAID Volume Status	100
Viewing Disk Drive Information	101
Creating a RAID Volume	101
Designating a Spare Drive	102
Migrating a RAID Volume	102
Deleting a RAID Volume	103
Viewing an External USB Drive or Memory Stick	104
Formatting an External USB Drive or Memory Stick	104
Managing Backups	105
Enabling One Touch Backup	105
Managing the Network Connection	106
Viewing Network Setup Information	106
Making Network Settings	106
Working with Jumbo Frames	107

Chapter 5: PASM, cont.

Making Management Settings	108
Viewing the Event Log	108
Setting up SMTP Authentication	108
Viewing the Email Alert List	109
Adding an Email Alert Recipient	109
Deleting an Email Alert Recipient	109
Upgrading the System Firmware	110
Enabling and Disabling the Buzzer	110
Viewing UPS Status	110
Setting up a UPS	111
Managing Services	112
Setting System Date and Time	112
Running the Network Time Protocol	112
Viewing the Results of NTP Synchronization	113
Rebooting the SmartStor	113
Shutting Down the SmartStor	114
Booting the SmartStor After a Shutdown	114
Locating the SmartStor	114
Viewing System Information	115
Viewing Enclosure Information	115
Enabling the Smart Fan	116

Chapter 6: Technology Background 117

Introduction to RAID	117
RAID 0 – Stripe	118
RAID 1 – Mirror	119
Choosing a RAID Level	120
RAID 0	120
RAID 1	120
RAID Volume Migration	121
RAID 0 to RAID 1	121
RAID 1 to RAID 0	121
RAID Volume Rebuilding	121
Partition and Format	122

Chapter 7: Troubleshooting	123
Responding to an Audible Alarm	123
Checking the System Status LED	124
Checking Disk Status LEDs	124
Replacing a Failed Disk Drive	124
Checking RAID Volume Status in PASM	125
SmartStor Responds to a Critical RAID Volume	125
Responding to an Invalid RAID Volume	126
Checking File System Status in PASM	127
Rebuilding the File System	127
Checking the Event Log in PASM	128
Responding to Events	129
Checking Enclosure Status in PASM	131
Resolving Connections with SmartNAVI	132
Solving Network Connection Problems	133
Checking Your Email Inbox	134
Restoring the Default Password	134
Resolving a Windows Firewall Issue	135
Chapter 8: Support	137
Frequently Asked Questions	137
Contacting Technical Support	140
Limited Warranty	143
Returning Product For Repair	145
Appendix A: Maintenance	147
Upgrading the Firmware	147
Upgrading the Software	148
Connection Problems After Restart	149
Appendix B: Important Information	151
GNU General Public License	151
Battery	151
Index	153

Chapter 1: Introduction to SmartStor

- About This Manual (page 1)
- Architecture (page 2)
- Protocol Support (page 2)
- Key Benefits (page 2)
- Specifications (page 3)
- Compatible Backup Software (page 4)
- Client OS Support (page 4)
- Browser Support (page 4)

Promise Technology's SmartStor NS2300N is a network attached storage (NAS) solution for external storage targeted for small and medium business (SMB) users and small office/home office (SOHO) users.

With a NAS product, users can save their work and have access to files over the network without having to carry around a disk drive or memory stick. The Administrator can manage access privileges for greater security. Multiple backup and synchronization functions protect your data.

About This Manual

This *Product Manual* describes how to setup, use, and maintain the SmartStor NS2300N. It also describes how to use the SmartNAVI software and Promise Advanced Storage Manager (PASM) software.

This manual includes a full table of contents, chapter task lists, and numerous cross-references to help you find the specific information you are looking for.

Also included are four levels of notices:



Note

A *Note* provides helpful information such as hints or alternative ways of doing a task.



Important

An *Important* calls attention to an essential step or point required to complete a task. Important items include things often missed.



Caution

A *Caution* informs you of possible equipment damage or loss of data and how to avoid them.



Warning

A *Warning* notifies you of probable equipment damage or loss of data, or the possibility of physical injury, and how to avoid them.

Architecture

The SmartStor NS2300N's architecture is based on the Freescale MPC8313 microprocessor and the Promise PDC20771 Serial ATA RAID Controller. The Gigabit Ethernet port is used for the data transfer and management. The USB port is used for a printer, expansion drives, and Uninterruptable Power Supply (UPS).

Protocol Support

SmartStor NS2300N supports:

- Windows 2000, XP Professional, 2003 Server, and Vista clients through SMB and CIFS protocols
- UNIX and Linux clients through the NFS protocol
- Macintosh clients through the AFP protocol
- FTP clients through the FTP protocol
- DLNA clients through UPnP protocol with an optional plug-in
- Up to 16 concurrent connections supported

Key Benefits

- Easy-to-use browser-based management interface
- Data sharing over the network
- One-touch backup of designated file folders on client PC
- Network print server with USB printer
- User, Group, and Quota management
- UPS support with automated shutdown
- Heterogeneous environment: Windows, UNIX, Linux, and Macintosh
- SmartNAVI setup and management software
- Promise Advanced Storage Manager (PASM) software

Specifications

- Disk drive support:
 - Two 1.5 Gb/s or 3 Gb/s SATA 3.5-inch disk drives
 - Conforms to Serial ATA 1.0 specification and Serial ATA II: Extensions to Serial ATA 1.0 specification (SATA II, phase I specification)
 - SATA specification of 3 Gb/s transfers with CRC error-checking
 - Hot-swapping of disk drives
 - Tagged command queuing
 - Native command queuing
 - Drive roaming among channels
 - S.M.A.R.T. status polled every 15 minutes
 - Online capacity expansion
 - RAID Level Migration
 - RAID Volume rebuilding
 - Gigabyte rounding
 - Background rebuilding
- RAID level support: RAID 0 and 1
- Large file system support up to 2 TB
- Unicode file name support
- SATA RAID Controller: Promise PDC20771
- Server on a Chip: Freescale MPC8313, 333MHz
- Networking: 10/100/1000 Mb/s Ethernet Port on motherboard
- USB port: USB 2.0, up to 480 Mb/s, one Type-A connector
- File protocols: SMB, CIFS, FTP, AFP, NFS
- Flash Memory: 32 MB, 8-bit
- Memory: 128 MB DDRII SDRAM
- Power Adapter: Input: 100-240V, 1.5A, 50-60 Hz AC. Output: 12V, 5A, DC
- Network Time Protocol (NTP) client
- Error logging
- Phone home capability (email notification) to contact IT staff
- Hardware monitoring of:
 - Fan
 - Temperature
 - Power
 - Disk status
 - One-Touch button
 - Enclosure status

Compatible Backup Software

SmartStor NS2300N is compatible with the following backup software products:

- VERITAS® NetBackup/Backup Exec™
- CA BrightStor™ ARCserve/Enterprise
- LEGATO® NetWorker™
- Syncsort Backup Express
- Microsoft Backup Software for Windows 95/98/NT/2000/ME/XP
- Dantz Retrospect for Macintosh

Client OS Support

Microsoft Windows:

- Vista Business, Enterprise, and Ultimate; Server 2003, XP Professional, 2000
- Supports Intel IA32, AMD64 and Intel EM64T platforms

UNIX/Linux:

- Red Hat Enterprise Linux 3.0 (AS/WS/ES)
- Red Hat Enterprise Linux 4.0 (AS/WS/ES)
- SuSe Linux Enterprise 10 (Server/Desktop)

Apple Macintosh:

- MacOS X

Browser Support

Use the latest version of the following browsers to manage the SmartStor NS2300N:

- Internet Explorer
- Netscape Navigator
- Mozilla
- Firefox
- Safari (MacOS X)

Chapter 2: Installation and Setup

- Unpacking the SmartStor NS2300N (page 5)
 - Installing Disk Drives (page 7)
 - Connecting to the Network (page 7)
 - Connecting the Power (page 7)
 - Installing the Software (page 8)
 - Setting up the SmartStor (page 11)
 - Connecting to PASM (page 15)
 - Shutting Down the SmartStor (page 18)
-

Unpacking the SmartStor NS2300N

The SmartStor NS2300N box contains the following items:

- SmartStor NS2300N Unit
- *Quick Start Guide*
- Screws for disk drives (1 package)
- Ethernet cable
- Power cord
- 12V DC Power Adapter
- CD with SmartNAVI software, *Product Manual* and *Quick Start Guide*



Warning


The electronic components within the SmartStor are sensitive to damage from Electro-Static Discharge (ESD). Observe appropriate precautions at all times when handling the SmartStor or its subassemblies.



Important


To configure the SmartStor, you must install the software onto a PC running Windows Vista, 2003 Server, XP Professional, or 2000.

Figure 1. SmartStor NS2300N Front View



Note: This SmartStor is shown without the front door.

Figure 2. SmartStor NS2300N Rear View



Installing Disk Drives

You can populate the SmartStor NS2300N with SATA 1.5 Gb/s or 3.0 Gb/s disk drives. For optimal performance, install disk drives of the same model and capacity. Your disk drives will become a RAID Volume on the SmartStor.

To install disk drives:

1. Open the door on the front of the SmartStor enclosure.
2. Pull a disk drive carrier from the enclosure. See Figure 1.
3. Carefully lay the disk drive into the drive carrier, so that the screw holes on the sides of the carrier align with the screw holes in the drive.
4. Insert the screws through the holes in the drive carrier and into the sides of the disk drive.
 - Install only the counter-sink screws supplied with the SmartStor.
 - Install four screws per disk drive.
 - Snug each screw. Be careful not to over-tighten.
5. Reinstall the drive carrier into the SmartStor enclosure.
Repeat steps 2 through 5 for the other disk drive.
6. Close the door on the front of the SmartStor.

Connecting to the Network

To connect the SmartStor to your network:

1. Attach one end of the network cable to the RJ45 network connection.
See Figure 2.
2. Attach the other end of the network cable to your Ethernet hub or switch.

Connecting the Power

To power the SmartStor:

1. Attach the power cord from the power source to the power adapter.
2. Connect the power adapter to the back of the SmartStor enclosure. See Figure 2.

3. On the front of the SmartStor, press the power button. See Figure 1.

It takes about a minute to boot the SmartStor. When fully booted:


- The System Status LED turns green. See Figure 1.
- The buzzer beeps one time.

Installing the Software

The SmartNAVI software connects your PC to the SmartStor, sets up the SmartStor, sets up network drives on your PC, and performs backups.

To install the software:

1. Insert the CD into your CDROM.
2. Double-click the **SmartNAVI** installer icon (right).
3. Click the **Next** button to begin installation.



The License Agreement screen appears.

- Click the “I accept the terms...” option, then click the **Next** button.



The Choose Destination Location screen appears.


- Optional. Click the **Browse...** button to choose a new install location for the software.

Click the **Next** button.



The Ready to Install screen appears.


6. Click the **Install** button to proceed with installation.



When the installation is finished, the final installation screen appears.

7. Click to **Finish** button to close the installer.

With the Online Registration box checked, your browser will open and go directly to the Promise product registration website. Thank you for taking the time to register.



The installer adds a SmartNAVI icon to the:

- Start menu
- Application tray

SmartNAVI loads automatically every time your Windows OS starts.


Setting up the SmartStor

The SmartNAVI performs the setup procedures on your SmartStor. After the procedure is done, you will have a default folder on the SmartStor, set up as a network drive on your PC.

You can change the network settings, create RAID volumes, add and mount folders on your SmartStor after initial setup using SmartNAVI. You can also made more advanced settings using the PASM software. See “Connecting to PASM” on page 15.

To set up your SmartStor:

1. Right-click the **SmartNAVI** icon in the Windows application tray (lower right corner of the screen).
2. Choose **Open SmartNAVI** from the popup menu.
The MSN Window opens.
3. Optional. From Language dropdown menu, choose the language you prefer.
4. Double-click the NS2300N in the NAS list.



The login window opens.

5. Type **admin** in the Username, Password, and Confirm fields, then click the **Login** button.



This action creates a default user and logs the default user into SmartNAVI. The Main Window opens.



Parameter	Value
NAS Name	ns4300n_3295729
Timezone	GMT-8
Date/Time	2008-01-22 22:44:27
IP Address	192.168.1.1
Storage Type	Automatic
Device Mapping	Y1


Wizard will set-up your NAS as specified.. Are you sure?

6. Choose a Setup Mode and click the button:
 - **One Click Setup** – Loads a collection of default settings. Recommended for most users.
 - **Advanced Setup** – Enables you to make your own settings. Recommended for advanced users.
7. Click the **OK** button to continue.

If you chose **One Click Setup**, the Wizard creates a RAID Volume and a default folder called *Public*. You are finished with the setup.

If you chose **Advanced Setup**, go to the next step.

8. Choose Automatic (DHCP) or Manual network settings.
If you chose Manual settings, type entries for each of the following parameters in the fields provided:
 - Computer (NAS system) Name
 - IP Address
 - Subnet Mask
 - Gateway
 - Primary and Secondary DNS – optional
9. Click the **Next** button to continue.
10. Choose the following values from their respective dropdown menus:
 - Timezone
 - Year
 - Month
 - Day
 - Time in Hours, Minutes, and Seconds
11. Click the **Next** button to continue.
12. Choose Automatic or Manual RAID Volume creation.
If you chose Manual, choose the type of RAID Volume you want:
 - Maximum Capacity – RAID 0, using both disk drives
 - Data Protection – RAID 1, using both disk drives
13. Click the **Next** button to continue.
14. Choose a network drive letter from the dropdown menu.
This drive will be mapped as a network drive on your PC.
The list begins with Z and goes in reverse alphabetical order.
15. Click the **Next** button to continue.
16. Review your parameters.
To make changes, click the **Previous** button.
To accept the parameters and configure your NAS system, click the **OK** button.
17. Click the **Yes** button in the confirmation box.
The Wizard creates a RAID Volume and a default folder called *Public*.
The Public folder on the SmartStor appears under My Computer as a network drive.



You can now copy files to and from the folder on the SmartStor.

To access this folder from other PCs, see “Chapter 3: Connecting to the SmartStor” on page 19.

To create additional RAID Volumes and folders, see “Chapter 5: PASM” on page 79.

Connecting to PASM

The Promise Advanced Storage Manager (PASM) software is factory-installed on the SmartStor system. PASM runs in the browser on your PC. You can access PASM:

- Directly in your browser (page 16)
- Through SmartNAVI (page 17)

Browser Support

Choose one of the following browsers to use with PASM:


- Internet Explorer
- Netscape Navigator
- Mozilla
- Safari (Mac OS X)
- Firefox

Finding the SmartStor's IP Address

To access the SmartStor in your browser, you must know the SmartStor's IP address. Use SmartNAVI for this purpose.

1. Right-click the **SmartNAVI** icon in the Windows application tray (lower right corner of the screen).
2. Choose **Open SmartNAVI** from the popup menu.

The SmartNAVI MSN window appears with the NAS List displayed. The IP address of the SmartStor shown in the NAS List.



IP address of the SmartStor detected on the network

For more information about SmartNAVI, see “Chapter 4: SmartNAVI” on page 45.

PASM in your Browser

To log into PASM in your browser:

1. Start your Browser.
2. In the Browser address field, type in the IP address of the SmartStor.

See “Finding the SmartStor’s IP Address” on page 15.

Note that the IP address shown below is only an example. The IP address you type into your browser might be different.

- PASM uses an HTTP connectionhttp://
- Enter the SmartStor’s IP address 192.168.1.1

Together, your entry looks like this: **http://192.168.1.1**

The PASM login screen displays.



© 2008 Promise Technology Inc. All rights reserved.

3. Type **admin** in both the User Name and Password fields, then click the **Login** button.

The user name and password are case sensitive.

For more information about PASM, see “Chapter 5: PASM” on page 79.

PASM in SmartNAVI

To log into PASM through SmartNAVI:

1. On the Windows desktop, right-click the **SmartNAVI** icon (right).
2. Choose **Open Advanced Management** from the popup menu.

Your default browser starts and the PASM login screen displays.

SmartNAVI icon



© 2008 Promise Technology Inc. All rights reserved.

3. Type **admin** in both the User Name and Password fields, then click the **Login** button.

The user name and password are case sensitive.


For more information about PASM, see “Chapter 5: PASM” on page 79.

Shutting Down the SmartStor

To shut down the SmartStor, press and hold the power button until the system status LED turns red. See Figure 3. When the system status LED goes dark, the SmartStor has shut down.

To restart the SmartStor, press the power button again.

Figure 3. Press and hold the Power button



Note: This SmartStor is shown without the front door.

Chapter 3: Connecting to the SmartStor

- Setting up a Network Drive on a Windows PC (page 19)
- Setting up a Network Drive on a UNIX or Linux PC (page 22)
- Setting up a Network Drive on a Macintosh PC (page 26)
- Connecting a USB Printer to SmartStor (page 29)
- Setting up the Print Server on SmartStor (page 30)
- Setting up Windows Printing (page 30)
- Setting up Linux Printing (page 32)
- Setting up Macintosh Printing (page 35)
- Connecting a USB Drive (page 37)
- Disconnecting a USB Drive (page 40)
- Setting-up Apple iTunes (page 40)

To copy files to and from a folder on the SmartStor, you must make the folder a network drive on your PC.


To use the SmartStor as a print server, you must connect the USB printer, enable SmartStor's print server, and set up printing on your PC.

Setting up a Network Drive on a Windows PC

You can also use SmartNAVI for this purpose, see "Mounting a Share Folder / Creating a Network Drive" on page 66. If your PC does not have SmartSYNC, use the following procedure to setup a Network Drive with My Network Places.

To setup a network drive:


1. On the Windows desktop, double-click the **My Network Places** icon.
2. Click the **Search** button in the toolbar.




If the Search button is not shown, from the View menu, choose *Toolbars*, then *Standard Buttons*.

3. In the Computer name field, type the IP address of the SmartStor and click the **Search** button.

See “Finding the SmartStor’s IP Address” on page 15.




The SmartStor appears in the search results list.



4. Double-click the **SmartStor** to show the Public folder and any other folders you have created.

- Right-click the folder you want and choose *Map Network Drive* from the dropdown menu.




The Map Network Drive dialog box appears.



- In the Map Network Drive dialog box, choose a drive letter and click the **Finish** button.
- Double-click the **My Computer** icon on your Windows desktop.

The folder on the SmartStor appears under My Computer as a network drive.




You can now copy files to and from the folder on the SmartStor.

Setting up a Network Drive on a UNIX or Linux PC


Before you can access the SmartStor from a UNIX or Linux PC, you must configure the SmartStor to communicate with UNIX and Linux.

On the Windows PC

1. Start PASM.
See "PASM in your Browser" on page 16 or "PASM in SmartNAVI" on page 17.
2. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree, then click the **Protocol Control** icon.



3. In the **Information** tab, click the **Enable** button next to **UNIX/Linux**.
4. Click the **OK** button in the confirmation box.
5. Click the **File Sharing** icon in the tree.
6. Click the **Modify** tab.



7. Check the **Unix/Linux** box, then click the **OK** button.
The UNIX/Linux file sharing enables UNIX and Linux PCs to access folders on the SmartStor. In this case, access is given for the PUBLIC folder.
8. Click the **Sharing Setup** icon in the tree.
9. Click the **UNIX/Linux Sharing** tab.



10. Optional. If you are creating a new folder, in the New IP Address field, type the IP address of the UNIX/Linux PC from which you want to access the SmartStor.

11. Click the **Add** button.

On the UNIX/Linux PC with Command Line Interface

1. Open a terminal window.
2. Create a new folder for the SmartStor. Type **mkdir SmartStor** and press Enter.
3. Mount the SmartStor. Type **mount 192.168.1.1:/VOLUME1/PUBLIC/SmartStor** and press Enter.

Note that the IP address shown above is only an example. The IP address you type in your terminal window will be different.

See “Finding the SmartStor’s IP Address” on page 15.

Volume1 and Public refer to the default Volume and folder created during setup. See page 11. If you created another volume or folder, use their names.


4. Change to the SmartStor directory. Type **cd /SmartStor** and press Enter.
You can now copy files to and from the folder on the SmartStor.
5. When you are done with the SmartStor, type **cd; umount /SmartStor** and press Enter.

On the Linux PC with Graphic Desktop

This procedure is for a RedHat Enterprise Linux 4 configuration. If you run a different version of Linux, you might have to adapt the procedure. See your OS documentation.


1. From the Applications menu, choose *Network Servers*.
2. In the Network window, double-click Windows Network.

3. Double-click the **SmartStor (NS2300)** on the network.



4. Double-click the folder you want.

If this is the first time you accessed this folder, an Authentication dialog box opens.



5. Type the user name and password in the respective fields, then click the **OK** button.

The default user name is **admin**. The default password is **admin**.

The user name and password are case sensitive.

Leave the Domain field blank.


The folder opens. You can now copy files to and from the folder on the SmartStor.

Setting up a Network Drive on a Macintosh PC


Before you can access the SmartStor from a Macintosh (MacOS X) PC, you must configure the SmartStor to communicate with the MacOS.

On the Windows PC

1. Start PASM.
See “PASM in your Browser” on page 16 or “PASM in SmartNAVI” on page 17.
2. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree, then click the **Protocol Control** icon.



3. In the **Information** tab, click the **Enable** button next to **Macintosh**.
4. Click the **OK** button in the confirmation box.
5. Click the **File Sharing** icon in the Tree.
6. Click the **Modify** tab.




7. Check the **Macintosh** box, then click the **OK** button.

The Macintosh file sharing enables Macintosh PCs to access folders on the SmartStor. In this case, access is given for the PUBLIC folder.

On the Macintosh PC

1. From the Go menu, choose *Connect to Server*.



2. In the Connect to Server dialog box, type **afp://192.168.1.1** and click the **Connect** button.

Note that the IP address shown below is only an example. The IP address you type in the dialog box on your Macintosh will be different.


See “Finding the SmartStor’s IP Address” on page 15.

Click the **+** button to add this IP address to the Favorite Servers list.




3. Type the user name and password in the respective fields, then click the **OK** button.

The default user name is **admin**. The default password is **admin**.
The user name and password are case sensitive.




4. In the NS2300 dialog box, click the folder you want, then click the **OK** button.



5. In the NS2300 Welcome screen, click the **OK** button.



A window opens on the Macintosh desktop to access the folder on the SmartStor.




You can now copy files to and from the folder on the SmartStor.

Connecting a USB Printer to SmartStor

To connect a USB printer to the SmartStor:


1. Set up your printer according to the printer's *Setup Guide* or *User Manual*.
2. Install the printer drivers onto your PC as described in the printer's *Setup Guide* or *User Manual*.
3. Attach the USB cable from your printer to one of the USB connections on the back of the SmartStor.



Setting up the Print Server on SmartStor

To set up the SmartStor's print server:

1. Start PASM.
See "PASM in your Browser" on page 16 or "PASM in SmartNAVI" on page 17.
2. In the Tree, on the left side of the PASM screen, click the **+** beside the **File & Print** icon to expand the Tree.
3. Click the **Protocol Control** icon, then click the **Printer Server** tab.
4. Click the **Enable** option button beside Printer Server.
5. Click the **OK** button to save your settings.



Setting up Windows Printing


To set up printing on a Windows PC:

1. On the Windows desktop, double-click the **My Network Places** icon.
2. Click the **Search** button in the toolbar.
If the Search button is not shown, from the View menu, choose *Toolbars*, then *Standard Buttons*.
3. In the Computer name field, type the IP address of the SmartStor and click the **Search** button in the side bar.
See "Finding the SmartStor's IP Address" on page 15.
The SmartStor appears in the search results list.
4. In the computer list, double-click the **SmartStor** to open it.
If the Connect to dialog box appears, type the user name and password in the respective fields, then click the **OK** button.
The default user name is **admin**. The default password is **admin**.

The user name and password are case sensitive.




5. Right-click the **usbptr1** icon folder and choose *Connect...* from the dropdown menu.




6. When the warning message about printer drivers appears, click the **OK** button to continue.

- In the Add Printer Wizard, click the Manufacturer and model name of your USB printer, then click the **OK** button.



- In the Add Printer Wizard, click the **OK** button.
- To verify printer installation, in the Windows Start menu, choose *Settings*, then *Printers and Faxes*.

The Printers and Faxes screen appears. The **usbptr1** is the USB printer on the SmartStor.




Setting up Linux Printing


This procedure is for a RedHat Enterprise Linux 4 configuration. If you run a different version of Linux, you might have to adapt the procedure. See your OS documentation.

- From the Applications menu, choose *System Settings*, then *Printing*.
Printer configuration window opens.
- Click the **New** button.
Add a new print queue dialog box opens.

3. Click the **Forward** button.
4. In the Name field, type a name for the printer, such as *NAS_printer*, a description, and click the **Forward** button.




5. From the Select a queue type dropdown menu, choose *Network Windows (SMB)*.
6. Scroll the list and click the **triangle** icon beside NS2300. USBPTR01 appears below NS2300. USBPTR01 represents the USB printer connected to the SmartStor.




7. Highlight *USBPTR01* and click the **Forward** button. The Authentication dialog box opens. In the User name and Password fields, type **admin**, then click the **OK** button.

The user name and password are case sensitive.




The Printer Model dialog box opens.

- From the dropdown menu, choose the manufacturer of your printer.
From the model list, highlight the model of your computer.
Then click the **Forward** button.



- Click the **Finish** button.


USBPTR01 is added to your printer list.



Setting up Macintosh Printing

To set up printing on a Macintosh PC:

1. From the Apple Menu, choose *System Preferences*.
2. Double-click the **Print & Fax** icon.
3. Click the **Setup Printers** button.
4. In the Printer List, click the **Add** icon.
The Printer List displays a new panel.
5. In the new panel, from the popup menus, choose:
 - Windows Printing
 - Workgroup
6. From the list, highlight the **SmartStor**, then click the **Choose** button.



A user name and password dialog box appears.

7. Type the user name and password in the respective fields, then click the **OK** button.

The default user name is **admin**. The default password is **admin**.


The user name and password are case sensitive.



The printer list displays a new panel.


8. Highlight the *USBPTR01* in the list.

USBPRT01 represents the USB printer connected to the SmartStor.



9. In the Printer Model popup menu, choose the make of your printer.
10. In the Model Name list, choose the model of your printer.


- Click the **Add** button.
USBPTR01 is added to your printer list.



Connecting a USB Drive

To connect a USB drive to the SmartStor, attach the USB cable from your external drive to one of the USB connections on the back of the SmartStor.

If you have a USB memory stick, attach it directly to one of the USB connections or use a USB cable, whichever is more convenient.




The USB drive or memory stick appears as a folder called *usbdisk* when you create your network drive. See the instructions on the following page.

SmartStor supports USB drives and memory sticks formatted to FAT32 and Ext3 file formats. If the SmartStor does not recognize the USB drive or memory stick, the

usbdisk folder does not appear. See “Formatting an External USB Drive or Memory Stick” on page 104.

Windows PC


The USB drive appears as a folder on the SmartStor when you create a network drive on a Windows PC.



Follow the procedure “Setting up a Network Drive on a Windows PC” on page 19, but choose the *usbdisk* folder instead of the *public* folder.

Linux PC


The USB drive appears as a folder on the SmartStor when you create a network drive on a Linux PC.



Follow the procedure “Setting up a Network Drive on a UNIX or Linux PC” on page 22, but choose the USBDISK folder instead of the PUBLIC folder.

Macintosh PC

The USB drive appears as a folder on the SmartStor when you create a network drive on a Macintosh PC.



Follow the procedure “Setting up a Network Drive on a Macintosh PC” on page 26, but choose the USBDISK folder instead of the PUBLIC folder.

Disconnecting a USB Drive

To disconnect a USB drive or memory stick from the SmartStor:

1. Be sure that no files on the USB drive or memory stick are still open.
2. Unplug the USB drive or memory stick from the SmartStor.
The SmartStor automatically unmounts the USB drive or memory stick.

Setting-up Apple iTunes

The iTunes server plug-in enables SmartStor to be a shared resource in the Apple iTunes user interface. You must perform the setup operation on the Windows PC where you installed SmartNAVI.

Downloading the iTunes Plug-in



To download the iTunes plug-in:

1. Download your iTunes plug-in from the [Promise Support Website](#).
Plug-in file names end with a .ppg extension.
2. Save the plug-in file to a convenient place on your PC.

Installing the iTunes Plug-in

To install the iTunes plug-in using SmartNAVI:

1. Right-click the **SmartNAVI** icon in the Windows application tray (lower right corner of the screen).
2. Choose **Open SmartNAVI** from the popup menu.



3. Double-click a system in the NAS List.



The Main Window opens.

4. Click the **NAS Management** icon.
5. Click the **Add Plugin** button.
6. Do one of the following actions:
 - Type the name of the plug-in file
 - Click the folder icon, navigate to the plug-in file, click it, then click the **Open** button
7. Click the **OK** button.



After a few moments, the plug-in is added.




Warning

Do not disconnect the power or shut down the SmartStor while the plug-in installation is running!

8. Click the **Configure Plugin** button.
The newly added plug-in appears in the list. Its Service Status is OFF.
9. Click the plug-in to choose it.

The plug-in's name turns red.



10. Click the **Enable** button.
After a moment, the Service Status changes to ON.
The plug-in is now installed SmartStor.



Note


You can also install the iTunes plug-in using PASM. See “Adding Plug-ins” on page 94 and “Enabling and Disabling Plug-ins” on page 95.

Installing and Configuring Apple iTunes

After you have installed the iTunes plug-in, your system is ready to install and configure iTunes.

1. Go to the Apple website and download iTunes.
2. Install iTunes onto your PC.
3. Be sure your SmartStor is running and connected to your network.
4. Open the iTunes application.
The SmartStor's network name appears on the iTunes screen under Shared.

Click on the SmartStor to display the items stored there.



Chapter 4: SmartNAVI

- Working with SmartNAVI (page 45)
 - Managing Users and Groups (page 50)
 - Managing RAID Volumes (page 55)
 - Managing Backups (page 58)
 - Managing Share Folders (page 64)
 - Making Management Settings (page 67)
 - Managing Downloads (page 75)
-

Working with SmartNAVI

The SmartNAVI software connects your PC to the SmartStor, performs backups, changes the network settings, create RAID volumes, add and mounts folders, and manages file downloads from the Internet.

This category includes the following topics:

- Opening SmartNAVI (page 45)
- Opening the MSN Window (page 46)
- Opening the Main Window (page 46)
- Choosing a SmartNAVI Language (page 47)
- Starting the Advanced Storage Manager (PASM) (page 47)
- Viewing SmartNAVI Information (page 48)
- Closing SmartNAVI (page 49)

Opening SmartNAVI

To open SmartNAVI:

1. Right-click the **SmartNAVI** icon in the Windows application tray (lower right corner of the screen).
2. Choose **Open SmartNAVI** from the popup menu.

SmartNAVI icon




Opening the MSN Window

To open the MSN Window, do one of the following actions:

- If the Main Window is open – Click the close  icon at the top right corner of the Main Window.
- If neither Window is open – Right-click the **SmartNAVI** icon in the application tray and choose **Open SmartNAVI** from the popup menu.

The MSN Window opens.



Opening the Main Window

To open the Main Window, do one of the following actions:

- If neither Window is open – Double-click the **SmartNAVI** icon in the application tray.

When the MSN Window opens, double-click a system in the NAS List.



- If the MSN Window is open – Double-click a system in the NAS List.
The Main Window opens.



Choosing a SmartNAVI Language

To choose a language:

1. Go to the **MSN Window**.
2. Click the **Language** dropdown menu and choose the language you prefer.



Starting the Advanced Storage Manager (PASM)

This feature opens Promise Advanced Storage Manager (PASM) in your default browser. See the PASM online help or “Chapter 5: PASM” on page 79 for more information.

You can open PASM from:

- MSN Window
- SmartNAVI tray icon
- Your browser

MSN Window

1. Click the system in the **NAS List** that you want to open in PASM.
2. Click the **Open Advanced Management** icon (right).
The PASM login screen appears in your browser.



SmartNAVI Tray Icon

1. Right-click the **SmartNAVI** icon in the application tray.
2. Choose **Open Advanced Management** in the popup menu.
The PASM login screen appears in your browser.

Browser

To use this method, you must know the IP address of the NAS system. See "Finding the SmartStor's IP Address" on page 15.

1. Open a browser window.
2. In the browser's address field, type the IP address of your NAS system.
Example: `http://192.168.1.183/`
3. Press the Enter key.
The PASM login screen appears in your browser.

Viewing SmartNAVI Information

SmartNAVI is the software application that connects your PC with the SmartStor NAS system.

To view information about SmartNAVI:

1. Right-click the **SmartNAVI** icon in the application tray.
2. Choose **About** from the popup menu.

The About window appears and lists the following information:

- SmartNAVI Version number
- Java Virtual Machine (JVM) Version number
- JVM Vendor name
- SmartNAVI installation directory on your PC
- SmartNAVI Plug-in directory on your PC
- Names of installed Plug-ins
- Version numbers of installed Plug-ins

When you are done with the About window, click the **Close** button.

Closing SmartNAVI

To close SmartNAVI:

1. Click the close  icon in the top right corner of the Main Window.
2. Click the close  icon in the top right corner of the MSN Window.

If you close SmartNAVI this way, you can open it from the application tray icon.

Alternative Method

To close SmartNAVI:

1. Right-click the **SmartNAVI** icon in the application tray.
2. Choose **Close** from the popup menu.

If you close SmartNAVI this way, you must open it from the Start menu.

Managing Users and Groups

This category includes the following topics:

- Creating a User (page 50)
- Creating the Default User (page 51)
- Changing User Passwords (page 51)
- Changing User Permissions (page 51)
- Viewing a List of Users (page 52)
- Deleting a User (page 52)
- Creating a Group (page 52)
- Viewing a List of Groups (page 53)
- Adding Members to a Group (page 53)
- Deleting Members from a Group (page 53)
- Deleting a Group (page 54)

Creating a User

To create a user:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Create New User** button.
4. Type a Username in the field provided.

Up to 16 characters, A-Z, 0-9, and _, first character must be a letter. No spaces.

5. Type a Password in the field provided.
Up to 16 characters, A-Z and 0-9. No spaces.
6. Retype the Password in the Confirm field.
7. Click the **OK** button.



Note

These users can access the share folders but not SmartNAVI or PASM.

Creating the Default User

This feature creates the default user for SmartNAVI.



Important

If you change to a new default user, the previous default user's network drives, backup schedules, username, and password information all will be deleted.

To create the default user:

1. Go to the **MSN Window**.
2. Click the **Default User** icon (right).

The Default User Setting dialog box opens.



OR

1. Right-click the **SmartNAVI** icon in the application tray.
2. Choose **Default User** from the popup menu.
3. Type the default username **admin** in the field provided.
4. Type the default password **admin** in the field provided.
5. Retype the password in the Confirm field.
6. Click the **Save** button.

To create additional users, see “Creating a User” on page 50.

Changing User Passwords

To change a user's password:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Modify User** button.
4. Click the user whose password you want to change.
5. Admin user only, type the old password in the field provided.
6. Type the new password in the field provided.
7. Retype the password in the Confirm field.
8. Click the **OK** button.

Changing User Permissions

The Admin user always has read and write permission. All other users have read-only permission by default.

To change permissions:

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Click the **Share Folder Permission** button.
4. Click the share folder whose permissions you want to change.
The folder name turns red.
5. For each user in the list, click one of the following options:
 - Deny access
 - Read only
 - Read and Write“Guest” is the only other default user.
6. Click the **OK** button.
The permission change happens immediately.

Viewing a List of Users

To view a list of Users:

1. Go to the Main Window.
2. Click the User Management icon.
The User List appears.

Deleting a User

To delete a user:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Delete User** button.
4. Click the user you want to delete.
5. Click the **OK** button.
6. Click the **Yes** button in the confirmation box.

Creating a Group

To create a Group:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Create New Group** button.

4. Type a Group name in the field provided.
Up to 16 characters, A-Z, 0-9, and _. No spaces.
5. Optional. Move members to the **Selected User** list to add them.
Or add them later.
6. Click the **OK** button.

Viewing a List of Groups

To view a list of Groups:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Group List** button.

Adding Members to a Group



Note

A User can only belong to one Group. If a User already belongs to a Group and you add him to this Group, you automatically delete him from the previous Group.

To add Users as Group members:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Modify Group Member** button.
4. Click the Group whose membership you want to change.
5. Move members to the **Selected User** list to add them.
6. Click the **OK** button.

Deleting Members from a Group



Note

Deleting a User from a Group does not delete the User from the System.

To delete Users from a Group:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Modify Group Member** button.

4. Click the Group whose membership you want to change.
5. Move members to the **Available User** list to delete them.
6. Click the **OK** button.

Deleting a Group

Before you can delete a Group, you must first delete all of the Members from the Group. See “Deleting Members from a Group” on page 53.

To delete a Group:

1. Go to the **Main Window**.
2. Click the **User Management** icon.
3. Click the **Delete User** button.
4. Click the Group you want to delete.
5. Click the **OK** button.
6. Click the **Yes** button in the confirmation box.

Managing RAID Volumes

This category includes the following topics:

- Creating a RAID Volume (page 55)
- Expanding a RAID Volume (page 55)
- Viewing RAID Volume Status (page 56)
- Viewing a List of RAID Volumes (page 56)
- Recreating a RAID Volume (page 57)

Creating a RAID Volume

To create a RAID volume:

1. Go to the **Main Window**.
2. Click the **Volume Configuration** icon.
3. Click the **Create Volume** button.
4. Choose Automatic or Manual RAID Volume creation.

If you chose Manual, choose the type of RAID Volume you want:

- Maximum Capacity – RAID 0, using both disk drives
 - Data Protection – RAID 1, using both disk drives
5. Click the **OK** button.

The RAID volume takes several minutes to create and initialize, depending on the size of your disk drives.



Note

When you create your RAID volume in PASM, you can choose additional options, such as Multiple RAID volumes.

See “Setting up SmartStor with the Setup Wizard” on page 83.

Expanding a RAID Volume

This feature adds disk drives to your existing RAID volume.

To expand a RAID volume:

1. Go to the **Main Window**.
2. Click the **Volume Configuration** icon.
3. Click the **Expand Volume** button.
4. Click the **OK** button.
5. Click the **Yes** button in the confirmation box.

The RAID volume takes several minutes to expand and initialize, depending on the size of your disk drives.



Notes

Expansion is only available when your NAS system has the proper combination of RAID volume and free disk drives.

For additional expansion options or to change the RAID level of your volume, use PASM.

See “Migrating a RAID Volume” on page 102.

Viewing RAID Volume Status

RAID Volume status includes:

- Volume name
- RAID level
- Capacity
- Usage – Percentage of capacity used
- Disk drive model and capacity

To view the status of a RAID Volume:

1. Go to the **Main Window**.
2. Click the **Volume Configuration** icon.
3. Click the **Volume Status List** button.

The Volume Status appears.

Viewing a List of RAID Volumes

To view a list of RAID Volumes:

1. Go to the **Main Window**.
2. Click the **Volume Configuration** icon.

The Volume List appears.

Recreating a RAID Volume



Caution

When you recreate a RAID volume, you delete all the data saved in the volume.

Back up any important data before you recreate a volume.

To recreate a RAID volume:

1. Go to the **Main Window**.
2. Click the **Volume Configuration** icon.
3. Click the **Recreate Volume** button.
4. Choose Automatic or Manual RAID Volume creation.

If you chose Manual, choose the type of RAID Volume you want:

- Maximum Capacity – RAID 0
 - Data Protection – RAID 1 or 5, depending on the NAS model and number of drives
5. Click the **OK** button.
 6. Click the **Yes** button in the first confirmation box.
 7. Type **YES** then click the **OK** button in the second confirmation box.
- The RAID volume takes several minutes to recreate and initialize, depending on the size of your disk drives.

Managing Backups

This category includes the following topics:

- Doing a Backup Now (page 58)
- Scheduling a Backup (page 59)
- Viewing Backup Schedules (page 60)
- Changing a Scheduled Backup (page 60)
- Deleting a Scheduled Backup (page 61)
- Restoring Backed-up Files (page 61)
- Viewing the Backup Event Log (page 62)
- Saving the Event Log (page 62)
- Clearing the Event Log (page 63)

Doing a Backup Now

This feature enables you to perform an immediate backup of your files.

You can perform an immediate backup of your files from:

- Main Window
- MSN Window
- SmartNAVI tray icon

Main Window

If you do not have a backup schedule for the NAS, start your backup from the Main Window.

1. Click the **SmartSYNC** icon.
2. Click the **Schedule List** button.
3. Check the boxes for the folders you want to backup.
4. Click the **Backup** button.

The backup begins immediately.

MSN Window

Before you can backup from the MSN Window, you must create a backup schedule. See “Scheduling a Backup” on page 59.

1. Click the system in the **NAS List** whose backup you want to run.
2. Click the **Do Backup Now** icon (right).

The backup begins immediately.



SmartNAVI Tray Icon

Before you can backup from the SmartNAVI tray icon, you must create a backup schedule. See “Scheduling a Backup” on page 59.

1. Right-click the **SmartNAVI** icon in the application tray.
2. Choose **Backup Now** in the popup menu.

The backup begins immediately.

The amount of time required depends on the size and number of files being backed up.

The backed up files will appear on the NAS system in a folder named **BACKUPDATA_**your username.

You can restore the backup files to your PC at any time.
See “Restoring Backed-up Files” on page 61.

Scheduling a Backup

You can schedule backups by the hour, day, or week.

To set a schedule for backing up files from your PC to the NAS system:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Backup/Schedule – NAS** button.
4. Click the folder whose contents you want to backup.
Click the arrow icons to expand the tree and narrow your choices.
5. Click the **Schedule** button.
6. Click an option button for:
 - Hour
 - Day
 - Day of the week
7. Choose the corresponding values from the dropdown menus:
 - Number of hours
 - Time of day in hours and minutes
 - Time of day and day of the week
8. Click the **Add** button.

The newly created schedule appears in the Schedule List.

The backed up files will appear on the NAS in a folder named **BACKUPDATA_**your username.

Viewing Backup Schedules

To view the list of current schedules:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Schedule List** button.

The list of all backup schedules appears.

Changing a Scheduled Backup

You can schedule backups by the hour, day, or week.

To change the scheduled backup of files from your PC to the NAS system:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Schedule List** button.
4. Click the schedule you want to change.
5. Click the **Modify** button.
6. Click the folder whose contents you want to backup.
Click the arrow icons to expand the tree and narrow your choices.
7. Click the **Schedule** button.
8. Click an option button for:
 - Hour
 - Day
 - Day of the week
9. Choose the corresponding values from the dropdown menus:
 - Number of hours
 - Time of day in hours and minutes
 - Time of day and day of the week
10. Click the **Add** button.

The modified schedule appears in the **Schedule List**.

Deleting a Scheduled Backup



Note

Deleting a scheduled backup has no effect upon any files previously backed-up to the SmartStor.

To delete a scheduled backup:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Schedule List** button.
4. Click the schedule you want to delete.
5. Click the **Delete** button.
6. Click the **Yes** button in the confirmation box.

Restoring Backed-up Files

You can restore all or any portion of the files in the **BACKUPDATA_your username** folder on the NAS system.

You can also choose to restore the files to their original location on your PC or an alternative location.

The original file structure is maintained during backup and restoration.



Caution

If you restore to the original folders on your PC, the restore function will overwrite the files in those folders.

Be careful which files you restore and where on your PC you direct the backup files.

To restore your backed-up files from the NAS system to your PC:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Restore** button.
4. Click the folder whose contents you want to restore.
Click the arrow icons to expand the tree and narrow your choices.
5. Click an option button for:
 - Restore to original folder – The backup files will overwrite the files on your PC
 - Restore to a specific folder – No files are overwritten on your PC

6. If you chose Restore to a specific folder, do one of the following actions:
 - Type the name of an existing folder in the field provided
 - Type the name of an new folder in the field provided
 - Click the Folder icon and navigate to the target folder
7. Click the **Restore** button.

The restoration begins immediately. The amount of time required depends on the size and number of files being restored.

Viewing the Backup Event Log

Backup events report on backups, schedules, and file transfers.

Events are reported by date, time, severity (information or error) and description.

To view Backup Event Log:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Event Log** button.
4. Optional. Set the Event Filter dropdown menu to display:
 - All events
 - Information events only
 - Error events only
5. Optional. Click the arrow on the **Date/Time** header to reverse the chronological order.



Note

For NAS system events, see “Viewing the System Event Log” on page 71.

Saving the Event Log

This function saves a copy of the Backup Event Log as a text file onto your PC. The text file records the events displayed in the Event Log window.

Set the Event Filter dropdown menu to display:

- All events
- Information events only
- Error events only

Click the arrow on the **Date/Time** header to reverse the chronological order.

To save a copy of the Backup Event Log as a text file:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Event Log** button.
4. Click the **Save** button.
5. Optional. Change the file name or save to a different location.
6. Click the **Save** button in the Save dialog box.

Clearing the Event Log



Note

Before you clear the Backup Event Log, consider saving a copy for future reference. See “Saving the Event Log” on page 62.

To clear the Backup Event Log:

1. Go to the **Main Window**.
2. Click the **SmartSYNC** icon.
3. Click the **Event Log** button.
4. Click the **Clear All** button.
5. Click the **Yes** button in the confirmation box.

Managing Share Folders

This category includes the following topics:

- Creating a Share Folder (page 64)
- Opening a Share Folder (page 64)
- Viewing a List of Share Folders (page 65)
- Changing Share Folder Permissions (page 65)
- Deleting a Share Folder (page 65)
- Mounting a Share Folder / Creating a Network Drive (page 66)
- Un-mounting a Share Folder / Disconnecting a Network Drive (page 66)

Creating a Share Folder

To create a new share folder:

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Click the **Create New Share Folder** button.
4. Type a folder name in the field provided.
Use A-Z, 0-9, - and _. No spaces.
5. Click the **Create** button.
6. Click the **Yes** button in the confirmation box.
The new folder appears in the Share Folder List.

Opening a Share Folder

This feature opens share folders in the file browser.

From the **MSN Window**:

1. Click the system in the **NAS List** whose share folders you want to open.
2. Click the **Open Share Folders** icon (right).
All share folders open on the NAS you chose.



From the **Main Window**:

1. Click the **Share Folder** icon.
2. Double-click the folder in the **Share Folder List** that you want to open.
The share folder opens in your PC's file browser.

Viewing a List of Share Folders

To view a list of Share Folders:

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Double-click the individual share folder to view its contents.

Changing Share Folder Permissions

The Admin user always has read and write permission. All other users have read-only permission by default.

To change permissions:

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Click the **Share Folder Permission** button.
4. Click the share folder whose permissions you want to change.

The folder name turns red.

5. For each user in the list, click one of the following options:

- Deny access
- Read only
- Read and Write

“Guest” is the only other default user.

6. Click the **OK** button.

The permission change happens immediately.

Deleting a Share Folder



Caution

When you delete a share folder, you delete all the data saved in the folder.

Back up any important data before you delete a folder.

To delete a share folder:

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Click the **Delete Share Folder** button.
4. Click the share folder you want to delete.

The folder name turns red.

5. Click the **OK** button.
6. Click the **Delete** button.
7. Click the **Yes** button in the first confirmation box.
8. Type **Yes** then click the **OK** button in the second confirmation box.

Mounting a Share Folder / Creating a Network Drive

To mount a share folder (Linux) or create a network drive (Windows):

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Click the **Mount Share Folder** button.
4. Click the share folder you want to mount or make a network drive.
The folder name turns red.
5. Choose a device name (drive letter) from the dropdown menu.
6. Click the **Map** button.
The share folder appears on your PC as a mounted or network drive.

Un-mounting a Share Folder / Disconnecting a Network Drive

To un-mount a share folder (Linux) or disconnect a network drive (Windows):

1. Go to the **Main Window**.
2. Click the **Share Folder** icon.
3. Click the **Mount Share Folder** button.
4. Click the share folder you want to un-mount or delete as a network drive.
The folder name turns red.
5. Click the **Un-Mount** button.
6. Click the **Yes** button in the confirmation box.
The share folder is un-mounted (Linux) or disconnected but the link remains (Windows).

Making Management Settings

This category includes the following topics:

- Configuring a NAS System (page 67)
- Changing Network Settings (page 69)
- Locating the SmartStor (page 70)
- Choosing a Default NAS System (page 70)
- Enabling or Disabling Event Notification (page 70)
- Viewing the System Event Log (page 71)
- Adding Plug-ins (page 71)
- Viewing a List of Plug-ins (page 72)
- Viewing Plug-in Version Numbers (page 72)
- Enabling and Disabling Plug-ins (page 73)
- Removing Plug-ins (page 73)

Configuring a NAS System

The Setup Wizard has two modes:

- **One Click Setup** – Loads a collection of default settings. Recommended for most users.
- **Advanced Setup** – Enables you to make your own settings. Recommended for advanced users.



Caution

Do NOT run the Setup Wizard on a NAS system that is already configured! That action will delete your data and network drives!

One Click Setup

To configure your NAS system using One Click Setup:

1. Go to the **Main Window**.
2. Click the **Setup Wizard** icon.
3. Click the **One Click Setup** button.
4. Click the **OK** button.

Advanced Setup

To configure your NAS system using Advanced Setup:

1. Go to the **Main Window**.
2. Click the **Setup Wizard** icon.

3. Click the **Advanced Setup** button.
4. Choose Automatic (DHCP) or Manual network settings.
If you chose Manual settings, type entries for each of the following parameters in the fields provided:
 - Computer (NAS system) Name
 - IP Address
 - Subnet Mask
 - Gateway
 - Primary and Secondary DNS – optionalClick the **Next** button to continue.
5. Choose the following values from their respective dropdown menus:
 - Timezone
 - Year
 - Month
 - Day
 - Time in Hours, Minutes, and SecondsClick the **Next** button to continue.
6. Choose Automatic or Manual RAID Volume creation.
If you chose Manual, choose the type of RAID Volume you want:
 - Maximum Capacity – RAID 0, using both disk drives
 - Data Protection – RAID 1, using both disk drivesClick the **Next** button to continue.
7. Choose a network drive letter from the dropdown menu.
This drive will be mapped as a network drive on your PC.
The list begins with Z and goes in reverse alphabetical order.
Click the **Next** button to continue.
8. Review your parameters.
To make changes, click the **Previous** button.
To accept the parameters and configure your NAS system, click the **OK** button.
9. Click the **Yes** button in the confirmation box.

**Note**

When you create your RAID volume in PASM, you can choose additional options, such as Multiple RAID volumes.

See “Setting up SmartStor with the Setup Wizard” on page 83.

Changing Network Settings

**Caution**

If your NAS system is on a network, check with your Network Administrator before you change the network settings. Incorrect settings can result in address conflicts and connection failures.

To change your network settings:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.
3. Click the **Network Setting** button.
4. Choose Automatic (DHCP) or Manual network settings.

If you chose Manual settings, type entries for each of the following parameters in the fields provided:

- Computer (NAS system) Name
 - IP Address
 - Subnet Mask
 - Gateway
 - Primary and Secondary DNS – optional
5. Click the **OK** button.
 6. Click the **Yes** button in the Network Setup box.
 7. Click the **OK** button in the Information box.
The **Main Window** closes and the **MSN Window** opens.
 8. Click your system in the **NAS List**.
The **Main Window** reopens.

Locating the SmartStor

This feature helps you to physically locate a NAS system.


To locate a SmartStor:

1. Go to the **MSN Window**.
2. Click the system in the **NAS List** that you want to locate.
3. Click the **Locate NAS** icon (right).



On the NAS system you chose:

- The buzzer sounds three times
- The Status LED blinks (right)



Choosing a Default NAS System

This feature sets the default NAS system (SmartStor) for the MSN window and SmartNAVI tray icon.

You are not required to set a default NAS. However, setting a default NAS activates several important functions, including:

- Opening a Share Folder
- Performing an Immediate Backup
- Starting the Advanced Storage Manager
- Enabling Event Notification

To set a default NAS:

1. Go to the **MSN Window**.
2. Click the system in the **NAS List** that you want to make the default.
3. Click the **Set Default NAS** icon (right).



The default NAS is highlighted in the NAS List.

Enabling or Disabling Event Notification

This feature displays popup notices of events on the default NAS system.

Enabling Event Notification

To enable event notification:

1. Right-click the **SmartNAVI** icon in the application tray.
2. Check **Event Notice** in the popup menu.

SmartNAVI displays a popup message indicating that event notification is working.

Disabling Event Notification

To disable event notification:

1. Right-click the **SmartNAVI** icon in the application tray.
2. Uncheck **Event Notice** in the popup menu.

Viewing the System Event Log

NAS events report functions and status of the NAS system. The Event Log displays the 20 most recent events.

Events are reported by date, time, severity (information or warning) and description.

To view the NAS system's Event Log:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.
3. Click the **Event Log** button.

Click the arrow on the **Date/Time** header to reverse the chronological order.



Note

For backup system events, see “Viewing the Backup Event Log” on page 62.

Adding Plug-ins

Application plug-ins are enhancements to SmartStor's capabilities. Available plug-ins include:

- **DLNA server** – Enables SmartStor to support the UPnP protocol and function as a Digital Media Server (DMS).
- **iTunes server** – Enables SmartStor to be a shared resource in the Apple iTunes user interface.
- **BT server** – Enables SmartStor to automatically download Bit Torrent, FTP, and HTTP files using SmartNAVI. See page 75.

SmartNAVI installs plug-ins from your PC. PASM installs plug-ins from a folder on the SmartStor. Also see “Adding Plug-ins” on page 94.

Download your plug-ins from the [Promise Support Website](#). Plug-in file names end with a .ppg extension. Save the plug-in file to a convenient place on your PC.

To add a plug-in to SmartStor:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.

3. Click the **Add Plugin** button.
4. Do one of the following actions:
 - Type the name of the plug-in file
 - Click the folder icon, navigate to the plug-in file, click it, then click the **Open** button
5. Click the **OK** button.
After a few moments, the plug-in is added.



Warning

Do not disconnect the power or shut down the SmartStor while the plug-in installation is running!

6. Click the **Configure Plugin** button.
The newly added plug-in appears in the list. Its Service Status is OFF.
7. Click the plug-in to choose it.
The plug-in's name turns red.
8. Click the **Enable** button.
After a moment, the Service Status changes to ON.

The plug-in is now installed SmartStor.

Viewing a List of Plug-ins

To view a list of installed plug-ins:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.
3. Click the **Configuration Plugin** button.
Currently installed plug-ins appear in the **Configuration Plugin** list.

Viewing Plug-in Version Numbers

To view plug-in version numbers:

1. Right-click the **SmartNAVI** icon in the application tray.
2. Choose **About** from the popup menu.
The About window appears. The About window includes a list of installed plug-ins and their version numbers.
When you are done with the About window, click the **Close** button

Enabling and Disabling Plug-ins

Enabling Plug-ins

You must add a plug-in to SmartStor before you can use this function.

To enable a plug-in:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.
3. Click the **Configuration Plugin** button.
4. Click the Plug-in you want to enable.

The plug-in's name turns red.

5. Click the **Enable** button.

After a moment, the Service Status changes to ON.

The plug-in is now enabled on SmartStor

Disabling Plug-ins

Disabling a plug-in saves memory space and processing time on the SmartStor. If you do not use a feature, consider disabling its plug-in.

To disable a plug-in:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.
3. Click the **Configuration Plugin** button.
4. Click the Plug-in you want to disable.

The plug-in's name turns red.

5. Click the **Disable** button.

After a moment, the Service Status changes to OFF.

The plug-in is now disabled.

Removing Plug-ins

There are two reasons to remove a plug-in:

- To replace the old plug-in with a new one
- You know that you will never use the plug-in

Before you remove a plug-in, consider disabling it, instead. See “Enabling and Disabling Plug-ins” on page 73.

To remove a plug-in:

1. Go to the **Main Window**.
2. Click the **NAS Management** icon.

3. Click the **Configuration Plugin** button.
4. Click the Plug-in you want to remove.
The plug-in's name turns red.
5. Click the **Remove** button.
6. Click the **Yes** button in the confirmation box.
The plug-in is removed from SmartNAVI.
If you need the plug-in later, you can reinstall it. See “Adding Plug-ins” on page 71.

Managing Downloads

This category includes the following topics:

- Adding a Link (page 75)
- Viewing the Download List (page 76)
- Removing a Link (page 76)
- Pausing and Resuming a Download (page 76)
- Viewing the Downloaded List (page 77)
- Opening a Downloaded File (page 77)
- Deleting a Downloaded File (page 77)

Adding a Link



Note

This feature requires a plug-in for each NAS system. See “Adding Plug-ins” on page 71.

SmartNAVI and the NAS system can download files using several protocols, including:

- Torrent
- HTTP
- FTP
- eDonkey

For Torrent files, use your browser to locate the file you want on the Internet and download its link to your PC. Then add the Torrent file link to the Download Station as described below.

To add a Torrent file download link:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Add New Link** button.
4. Do one of the following actions:
 - Type the link into the field provided.
 - Click the folder icon, navigate to the link, click it, then click the **Open** button.
5. Click the **Add** button.

The file's link is added to the **Download List**. Downloading begins automatically. Torrent files are saved to the **download** folder on the NAS system.

Viewing the Download List

The Torrent files in this list have not been downloaded yet.

To view the Download List:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Download List** button.

Downloading began automatically when you added the links.

Torrent files are saved to the **download folder** on the NAS system.

Removing a Link

When you remove a link, the Download Station does not download the corresponding Torrent file.

To remove a Torrent file download link:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Download List** button.
4. Click the file link you want to remove.
5. Click the **Remove** button.
6. Click the **Yes** button in the confirmation box.

Pausing and Resuming a Download

Pausing a Download

To pause a Torrent file download:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Download List** button.
4. Click the link of the file download you want to pause.
5. Click the **Pause** button.

Resuming a Download

To resume a Torrent file download:

1. Go to the **Main Window**.

2. Click the **Download Station** icon.
3. Click the **Download List** button.
4. Click the link of the paused file download you want to resume.
5. Click the **Start** button.

Viewing the Downloaded List

The Torrent files in this list have been downloaded.

To view a list of downloaded files:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Downloaded List** button.

Torrent files are saved to the **download** folder on the NAS system.

Opening a Downloaded File



Note

This feature requires a plug-in for each NAS system. See “Adding Plug-ins” on page 71.

To open a downloaded file:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Downloaded List** button.
4. Click the file you want to open.
5. Click the **Open** button.

Deleting a Downloaded File



Caution

The feature deletes Torrent files from the **download** folder on the NAS system.

To delete a downloaded Torrent file:

1. Go to the **Main Window**.
2. Click the **Download Station** icon.
3. Click the **Downloaded List** button.

4. Click the file you want to delete.
5. Click the **Delete** button.
6. Click the **Yes** button in the confirmation box.

The link and corresponding Torrent file in the download folder on the NAS system are deleted.

Chapter 5: PASM

- Connecting to PASM (below)
 - Choosing a Language (page 82)
 - Navigating in PASM (page 82)
 - Logging out of PASM (page 82)
 - Setting up SmartStor with the Setup Wizard (page 83)
 - Managing Users and Groups (page 85)
 - Managing File & Print Services (page 90)
 - Managing RAID Volumes (page 100)
 - Managing Backups (page 105)
 - Managing the Network Connection (page 106)
 - Making Management Settings (page 108)
 - Managing Services (page 112)
-

Connecting to PASM

The Promise Advanced Storage Manager (PASM) software is factory-installed on the SmartStor system. PASM runs in the browser on your PC. You can access PASM:

- Directly in your browser. See page 80.
- Through SmartNAVI. See page 81.

PASM in your Browser

To log into PASM in your browser:

1. Start your Browser.
2. In the Browser address field, type in the IP address of the SmartStor.

See “Finding the SmartStor’s IP Address” on page 15.

Note that the IP address shown below is only an example. The IP address you type into your browser will be different.

- PASM uses an HTTP connectionhttp://
- Enter the SmartStor’s IP address 192.168.1.194

Together, your entry looks like this: **http://192.168.1.194**

The PASM login screen displays.



© 2008 Promise Technology Inc. All rights reserved.

3. Type the user name and password in the respective fields, then click the **Login** button.

The default user name is **admin**. The default password is **admin**.

The user name and password are case sensitive.

PASM in SmartNAVI

To log into PASM through SmartNAVI:

1. On the Windows desktop, right-click the **SmartNAVI** icon (right).
2. Choose **Open Advanced Management** from the popup menu.

Your default browser starts and the PASM login screen displays.

SmartNAVI icon



© 2008 Promise Technology Inc. All rights reserved.

3. Type the user name and password in the respective fields, then click the **Login** button.

The default user name is **admin**. The default password is **admin**.

The user name and password are case sensitive.

Choosing a Language


To choose a language, click the Language menu in the PASM Header and choose the language you prefer.

Navigating in PASM

The Tree is the primary navigation tool in PASM. Categories of functions listed with a + sign before the icon.

Icons for specific functions are listed under the categories. Click the + sign to show the functions.

Click the function icons to display their information on the screen. Each function has one or more tabs in its screen.



Logging out of PASM

There are two ways to log out of PASM:

- Close your browser window.
- Click **Logout** in the PASM Header.



Clicking **Logout** brings you back to the Login Screen. After logging out, you must enter your user name and password in order to log in again.

Setting up SmartStor with the Setup Wizard

If you used the SmartNAVI Setup Wizard to set up your SmartStor, you do not need to run the Setup Wizard in PASM.

If you have not yet set up your SmartStor:

1. In the Tree, click the **+** beside the **Wizard** icon, then on the **Setup Wizard** icon to display the Setup Wizard screen.

2. Click the **Next** button to start the Setup Wizard.

The Step 1 screen appears.

3. Optional. In the Computer Name field, enter a name for the SmartStor. Use only letters, numbers, and the underscore character for the name.

4. Under network configuration, choose one of the following options:

- **Configure using DHCP** – Choose this option if your network has a DHCP server with addresses available
- **Configure using Specify an IP address** – Choose this option if you want to set the IP address and other network setting manually

5. If you chose the *Configure using Specify an IP address* option, type the following information in the fields provided:

- IP Address
- Subnet Mask
- Default Gateway IP Address
- Primary DNS
- Secondary DNS

See your Network Administrator for help with these settings.

6. Click the **Next** button to continue.

The Step 2 screen appears.

7. Optional. Type a new administrator password into the New Password field.

Retype the new password into the Retype Password field.

8. Optional. To add a user, click the **Add new user** option button.

9. If you clicked the **Add new user** option button, type a user name and password into the fields provided, then click the **Add** button.

10. Click the **Next** button to continue.

The Step 3 screen appears.

11. Check the Enable box to the right of the services you plan to use.
 - **Windows** – Enables file access from Windows PCs. Also required to use the SmartStor as a print server.
 - **Unix/Linux** – Enables file access from Unix and Linux PCs
 - **Macintosh** – Enables file access from Macintosh PCs
 - **FTP** – Enables file access from PCs using FTP
12. Optional. Type new names into the Workgroup Name and Computer Description fields.
13. Click the **Next** button to continue.

The Step 4 screen appears.

You must add at least one folder, which you will access from your PC as a networked drive.
14. To add a folder, click the **Add new folder** option button.
15. Type a folder name into the field provided, check the boxes of the services you expect to use with this folder, then click the **Add** button.

Add more folders as required.
16. Click the **Next** button to continue.

The Step 5 screen appears.

If a RAID Volume already exists on the SmartStor, information about the RAID Volume is shown. To change the RAID, you must delete it first, then run the Setup Wizard again. See “Deleting a RAID Volume” on page 103.
17. From the RAID Level dropdown menu, choose the RAID level you want for your disk array.

See for “Choosing a RAID Level” on page 106 more information.
18. Highlight disk drives in the Free Disks column and click the **>>** button to move them to the Disks in RAID column.
19. Click the **Next** button to continue.

The Finish screen appears.
20. Click the **Finish** button to set up your SmartStor.

The setup process takes several minutes, depending on the size of your disk drives.

Managing Users and Groups

This category includes the following topics:

- Viewing a List of Users (page 85)
- Creating a User (page 85)
- Changing the Administrator's Password (page 85)
- Changing a User's Password (page 86)
- Deleting a User (page 86)
- Viewing a List of Groups (page 86)
- Creating a Group (page 87)
- Adding Members to a Group (page 87)
- Removing Members from a Group (page 87)
- Deleting a Group (page 88)
- Viewing Quotas (page 88)
- Setting Quotas (page 88)

Viewing a List of Users

To view the list of Users:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.

A list of users appears on the Information tab.

Creating a User

You can create up to 512 Users.

To create or add a new user:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
3. Click the **Create User** tab.
4. Type a user name in the field provided.
5. Type a password into the fields provided.
6. Click the **OK** button.

Changing the Administrator's Password

To change the Administrator's password:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.

3. Click the **Change Password** tab.
4. Type a new password into the fields provided.
5. Click the **OK** button.

If you forget your new password, you reset the SmartStor to the default Administrator's password. See "Restoring the Default Password" on page 124.

Changing a User's Password

To change a user's password:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
3. Click the **Change Password** tab.
4. From the User Name dropdown menu, choose the name of the user whose password you want to change.
5. Type a new password into the fields provided.
6. Click the **OK** button.

Deleting a User

You cannot delete the Administrator or the Guest. To delete any other user:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
3. Click the **Delete User** tab.
4. Click the option button to the left of the user you want to delete.
5. Click the **OK** button.
6. In the confirmation box, click the **OK** button.

Viewing a List of Groups

Groups are composed of users. You can assign permissions to a group, the same as you would do with individual users.

To view a list of groups:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.

A list of groups appears on the Information tab.

Creating a Group

Groups are composed of users. You can assign permissions to a group, the same as you would do with individual users. You can create up to 256 groups.

To create a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Create** tab.
4. Type a group name in the field provided.
5. Click the **OK** button.

Adding Members to a Group

You must create a group before you can assign members to it. See “Creating a Group” on page 87.

To add members to a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Group Members** tab.
4. From the dropdown menu, choose a group to which you want to add members.
5. Highlight users in the Users column and click the **>>** button to move them to the Members column.
6. Click the **OK** button.

Removing Members from a Group

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Group Members** tab.
4. From the dropdown menu, choose a group from which you want to remove members
5. Highlight users in the Members column and click the **<<** button to move them to the Users column.
6. Click the **OK** button.

Deleting a Group

You must remove all members from the group before you can delete the group. See “Removing Members from a Group” on page 87.

To delete a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Delete** tab.
4. Click the option button next to the group you want to delete.
5. Click the **OK** button.

Viewing Quotas

Quotas are portions of storage space that you assign to each user or group.

To view a quota:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Quota** icon.

A list of users and groups, and the following data appear on the screen:

- Currently assigned quotas
- Free space
- Used space

Setting Quotas

Quotas are portions of storage space that you assign to each user or group. Assigning quotas enables you to control how much storage space each user or group can access.

By default, each user and group is assigned an unlimited quota, meaning that any one user or group can access the entire storage space. In the Quota screen, the names of groups are preceded with a **@** symbol.

To set a quota:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Quota** icon.
3. Click the **Settings** tab.
4. Highlight the user or group whose quota you want to assign.
5. Click one of the following options:
 - Unlimited
 - Limited Quota

6. If you chose Limited Quota, type a number into the field provided.
This number represents how many MB of data the user or group can access.
7. Click the **OK** button.



Note

If you set different size quotas for the user and the group, SmartStor will use the smaller quota.

Managing File & Print Services

This category includes the following topics:

- Setting up Windows Access (page 90)
- Setting up UNIX/Linux Access (page 91)
- Setting up for Macintosh Access (page 92)
- Setting up for FTP Access (page 93)
- Setting up your Print Server (page 94)
- Adding Plug-ins (page 94)
- Viewing a List of Plug-ins (page 95)
- Enabling and Disabling Plug-ins (page 95)
- Removing Plug-ins (page 96)
- Viewing a List of Folders (page 96)
- Modifying Folder Services (page 96)
- Adding a Folder (page 97)
- Deleting a Folder (page 97)
- Setting up Windows Sharing for a Folder (page 98)
- Setting up UNIX and Linux Sharing for a Folder (page 98)
- Setting up FTP Sharing for a Folder (page 99)

Setting up Windows Access

To set up access from a Windows PC:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **Windows** tab.
4. Click the **Enable** option button beside Services.
5. Optional. Type a new Computer Description into the field provided.
6. Choose the option button to make the SmartStor a member of:
 - An Active Directory (AD) Domain
 - A Workgroup

Note: If you join an AD Domain, you automatically disable your NIS Domain settings. See “Setting up UNIX/Linux Access” on page 91.

7. Optional. If you chose an AD Domain, enter the following in the fields provided:
 - Domain Name
 - Domain Controller

- Administrator Name
 - Administrator Password
- See your Network Administrator for help with this information.
8. Optional. If you chose an Workgroup, enter the Workgroup name into the field provided:
See your Network Administrator for help with this information.
 9. Click the **OK** button to save your settings.
 10. In the Tree, click the **+** beside the **Sharing Setup** icon.
 11. Click the **Windows Sharing** tab.
 12. Choose a folder from the Folder Name dropdown menu.
 13. In the User/Group list, highlight the name of a user or group.
Group names are preceded by the **@** character.
 14. Under Permissions, choose a permission level for this user or group:
 - Deny Access
 - Read Only
 - Read and Write
 15. Click the **OK** button to save your settings.
You can now access the folder you chose from a Windows PC.
See “Chapter 3: Connecting to the SmartStor” on page 21 for information about the settings that you must make on your PC.



Note

Windows support is only through SMB and CIFS protocols. SmartStor supports the Recycle Bin feature. When you delete a file, the file is moved to the Recycle Bin, a hidden folder in the share folder.

Setting up UNIX/Linux Access

To set up access from a UNIX or Linux PC:

1. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree, then click the **Protocol Control** icon.
2. In the **Information** tab, click the **Enable** button next to **UNIX/Linux**.
3. Click the **OK** button in the confirmation box.
4. Optional. To joining a NIS Domain, click the **UNIX/Linux** tab, then click the **Enable** option button beside Services.

Note: If you join an NIS Domain, you automatically disable your AD Domain settings. See “Setting up Windows Access” on page 90.

5. Enter the Domain name into the field provided.
See your Network Administrator for help with this information.
6. Click the **OK** button to save your settings.
7. In the Tree, click the **+** beside the **File Sharing** icon.
8. Click the **Modify** tab.
9. From the Folder name dropdown menu, choose the folder you want to access.
10. Check the **UNIX/Linux** box.
11. Click the **OK** button to save your settings.
12. In the Tree, click the **+** beside the **Sharing Setup** icon.
13. Click the **UNIX/Linux Sharing** tab.
14. Choose a folder from the Folder Name dropdown menu.
15. In the New IP Address field, type the IP address of the UNIX or Linux PC from which you will access this folder, then click the **Add** button.
You must designate the IP addresses for each folder individually. You can have up to 256 IP addresses for all of your folders.
16. Click the **OK** button to save your settings.
You can now access the folder you chose from a UNIX or Linux PC.
See "Chapter 3: Connecting to the SmartStor" on page 21 for information about the settings that you must make on your PC.

Setting up for Macintosh Access

To set up access from a Macintosh PC:

1. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree, then click the **Protocol Control** icon.
2. In the **Information** tab, click the **Enable** button next to **Macintosh**.
3. Click the **OK** button in the confirmation box.
4. In the Tree, click the **+** beside the **File Sharing** icon.
5. Click the **Modify** tab.
6. From the Folder name dropdown menu, choose the folder you want to access.
7. Check the **Macintosh** box.
8. Click the **OK** button to save your settings.
You can now access the specified folder from a Macintosh PC.
See "Chapter 3: Connecting to the SmartStor" on page 21 for information about the settings that you must make on your PC.

Setting up for FTP Access

To set up FTP access for your folders:

1. In the **Information** tab, click the **Enable** button next to **FTP**.
2. Click the **OK** button in the confirmation box.
3. To change FTP settings, click the **FTP Sharing** tab.
4. To specify a new Command Port number, type the number into the field provided.

Port 21 is typically used for the Command Port.

5. To specify a range of passive data port numbers, type those numbers into the fields provided.

The port range is 1024 to 65535.

Be sure the port numbers you enter are enabled on your firewall and server.

In active mode, the FTP server uses port 20 for the data port.

6. If your FTP client uses double-byte characters but does not support Unicode, choose your FTP client's encoding from the Client Coding Type dropdown menu. Choose from:

- Unicode
- Shift-JIS
- GB2312
- BIG5

7. Click the **OK** button to save your settings.
8. In the Tree, click the **+** beside the **File Sharing** icon, then click the **Modify** tab.
9. From the Folder name dropdown menu, choose the folder you want to access.
10. Check the **FTP** box.
11. Click the **OK** button to save your settings.

You can now access the specified folder from your PC using FTP.

Setting up your Print Server

Your USB printer must be connected to the SmartStor and powered before you can set up the Print Server.

To set up the SmartStor as a printer server:

1. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree.
2. Click the **Protocol Control** icon, then click the **Printer Server** tab.
3. Click the **Enable** option button beside Printer Server.
4. Click the **OK** button to save your settings.



Notes

- The Printer Server tab also verifies that your USB printer is connected and online. If you do not see your printer on the Printer Server tab, take the necessary action to connect and power the printer. See “Connecting a USB Printer to SmartStor” on page 31.
 - The software driver for your printer must be installed on your PC before you can print from the PC. See the printer’s *Setup Guide* or *User Manual*.
-

Adding Plug-ins

Application plug-ins are enhancements to SmartStor’s capabilities. Available plug-ins include:

- **DLNA server** – Enables SmartStor to support the UPnP protocol and function as a Digital Media Server (DMS).
- **iTunes server** – Enables SmartStor to be a shared resource in the Apple iTunes user interface.
- **BT server** – Enables SmartStor to automatically download Bit Torrent, FTP, and HTTP files using SmartNAVI. See page 75.

PASM installs plug-ins from a folder on the SmartStor. SmartNAVI installs plug-ins from your PC. Also see “Adding Plug-ins” on page 71.

Download your plug-ins from the [Promise Support Website](#). Plug-in file names end with a .ppg extension. Place the plug-in file into a folder on the SmartStor.

To add a plug-in to SmartStor:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **System Upgrade** icon, then click the **Application Plug-in** tab.
3. From the Volume dropdown menu, choose the Volume that has the folder with the plug-in file.

4. From the Folder dropdown menu, choose the Folder that contains the plug-in file.
5. In the File Name field, type the name of the plug-in file.
Or highlight the file and copy the name, then paste the name into the field.
6. Click the **OK** button to begin the installation.



Warning

Do not disconnect the power or shut down the SmartStor while the plug-in installation is running!

When the installation is done, PASM displays a notification dialog box.

7. Click the **OK** button in the dialog box.

Viewing a List of Plug-ins

To view a list of installed plug-ins:

1. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree.
2. Click the **Protocol Control** icon.

A list of installed plug-ins and their version numbers appear on the **Information** tab.

Enabling and Disabling Plug-ins

Enabling Plug-ins

You must add a plug-in to SmartStor before you can use this function.

To enable a plug-in:

1. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree.
2. Click the **Protocol Control** icon.
3. In the **Information** tab, click the **Enable** button next to the plug-in you want to enable.
4. Click the **OK** button in the confirmation box.

After a moment, the Service Status changes to ON.

The plug-in is now enabled on SmartStor

Disabling Plug-ins

Disabling a plug-in saves memory space and processing time on the SmartStor. If you do not use a feature, consider disabling its plug-in.

To disable a plug-in:

1. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree.

2. Click the **Protocol Control** icon.
3. In the **Information** tab, click the **Disable** button next to the plug-in you want to disable.
4. Click the **OK** button in the confirmation box.
After a moment, the Service Status changes to OFF.
The plug-in is now disabled.

Removing Plug-ins

There are two reasons to remove a plug-in:

- To replace the old plug-in with a new one
- You know that you will never use the plug-in

Before you remove a plug-in, consider disabling it, instead. See “Enabling and Disabling Plug-ins” on page 95.

PASM has no mechanism to remove a plug-in. To remove a plug-in, you must use SmartNAVI. See page 73.

Viewing a List of Folders

A folder is the entity that appears as a Network Drive on your PC.

To view the list of folders:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.

A list of current folders appears in the Information tab.

Modifying Folder Services

Services enable different types of PCs to access your folders. Use this function to add or remove a service for a specific folder.

To modify the services on a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.
3. Click the **Modify** tab
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. Check the boxes beside the services you want to use.
7. Click the **OK** button.

If the service you want is OFF, see:

“Setting up Windows Access” on page 90

“Setting up UNIX/Linux Access” on page 91

“Setting up for Macintosh Access” on page 92

“Setting up for FTP Access” on page 93

Adding a Folder

A folder is the entity that appears as a Network Drive on your PC.

To add a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.
3. Click the **Create** tab.
4. From the Volume dropdown menu, choose the RAID Volume in which you want to create a new folder.
5. In the Folder Name field, type a name for your new folder.
6. Check the boxes beside the services you want to use.
7. Click the **OK** button.

To access the new folder from a Windows PC, see “Setting up Windows Sharing for a Folder” on page 98.

To access the new folder from a UNIX or Linux PC, see “Setting up UNIX and Linux Sharing for a Folder” on page 98.

To make the folder a network drive on your PC, see “Chapter 3: Connecting to the SmartStor” on page 21.

Deleting a Folder



Caution

When you delete a folder, you delete all the data saved in the folder. Back up any important data before you delete a folder.

To delete a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.
3. Click the **Remove** tab
4. Click the option button beside the folder you want to delete.
5. Click the **OK** button.

6. In the confirmation box, click the **OK** button to confirm.

Setting up Windows Sharing for a Folder

Windows sharing assigns user access the folders on your SmartStor. By default all users and groups have read-only access.

To set up Windows sharing for a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Sharing Setup** icon.
3. Click the **Windows Sharing** tab.
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. In the Permission list, click the option button for one of the following permissions for each group and user:
 - Deny Access
 - Read Only
 - Read and Write
7. Click the **OK** button.

Be sure the Windows service is running for this folder. See “Setting up Windows Access” on page 90.

Setting up UNIX and Linux Sharing for a Folder

UNIX and Linux sharing designates which UNIX and Linux PCs can access the folders on your SmartStor. You specify a UNIX or Linux PC by its IP address. You can add up to 256 IP addresses for all of your folders.

You must designate the IP addresses for each folder individually.

To set up UNIX and Linux sharing for a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Sharing Setup** icon in the tree.
3. Click the **UNIX/Linux Sharing** tab.
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. In the New IP Address field, type the IIP address of the UNIX or Linux PC from which you will access this folder.

7. Click the **Add** button.

Be sure the UNIX/Linux service is running for this folder. See “Setting up UNIX/Linux Access” on page 91.

Setting up FTP Sharing for a Folder

FTP sharing assigns user access the folders on your SmartStor. By default all users and groups have read-only access.

To set up FTP sharing for a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Sharing Setup** icon.
3. Click the **FTP Sharing** tab.
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. In the Permission list, click the option button for one of the following permissions for each group and user:
 - Deny Access
 - Read Only
 - Read and Write
7. Click the **OK** button.

Be sure the FTP service is running for this folder. See “Setting up for FTP Access” on page 93.

Managing RAID Volumes

This category includes the following topics:

- Viewing RAID Volume Status (page 100)
- Viewing Disk Drive Information (page 101)
- Creating a RAID Volume (page 101)
- Designating a Spare Drive (page 102)
- Migrating a RAID Volume (page 102)
- Deleting a RAID Volume (page 103)
- Viewing an External USB Drive or Memory Stick (page 104)
- Formatting an External USB Drive or Memory Stick (page 104)

Viewing RAID Volume Status

RAID status refers to the disk drives on your SmartStor and how they are arranged into a RAID Volume.

To view the status of your RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.

The RAID Status tab displays the current RAID system and its status:

- **RAID Name** – The name of your RAID, automatically assigned when it was created
- **RAID Level** – RAID 0 or 1 specified when it was created
- **Capacity** – Data capacity of the RAID Volume in GB
- **RAID Status** – Functional is normal. Critical means a disk drive has failed. Offline means you cannot access your data.
Critical and offline RAIDs require you to take corrective action. See “Replacing a Failed Disk Drive” on page 113.
- **Action Status** – Idle is normal. Rebuilding means the RAID Volume is being rebuilt after a disk drive failure. Migrating means the RAID Volume is adding a disk drive or changing RAID levels.
- **Background Activity** – None is normal. Running means a background activity is in progress.

Viewing Disk Drive Information

To view information about a disk drive:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.

The RAID Status tab displays the current RAID system and its status.

3. In the Disk List, double-click a disk drive icon.

The disk drive information displays under Disk Status.

Creating a RAID Volume

On SmartStor, the term RAID Volume refers to one or more disk drives working together as a RAID logical drive.

You can also use a USB disk to create a RAID Volume. See “Viewing an External USB Drive or Memory Stick” on page 104.

You must have unassigned disk drives in your SmartStor to create a new RAID.

To create a new RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Create** tab.
4. From the RAID Level dropdown menu, choose the RAID level you prefer for your disk array.

See “Choosing a RAID Level” on page 106 for more information.

5. Highlight disk drives in the Free Disks column and click the **>>** button to move them to the Disks in RAID column.
6. Click the **OK** button.

The RAID Volume is created and formatting begins. Formatting requires several minutes, depending on the size of your disk drives.

After formatting is done, you must create folders on your RAID Volume. See “Adding a Folder” on page 97.

Designating a Spare Drive

If you have an unassigned disk drive, you can assign it as a spare drive.

For more information, see “Spare Drive” on page 107 and “Automatic Rebuilding” on page 108.

To assign a spare drive:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Create** tab.
4. From the RAID Level dropdown menu, choose *Spare Disk*.
5. Highlight a disk drive in the Free Disks column and click the **>>** button to move it to the Disks in RAID column.
6. Click the **OK** button.

Migrating a RAID Volume

To migrate a RAID Volume means to change its RAID level or to add disk drives. See “RAID Volume Migration” on page 109 for more information.

To migrate a RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Modify** tab.
4. From the Current Volume dropdown menu, choose the RAID Volume which you want to modify.
5. In the Migrate to RAID Level dropdown menu, choose the target RAID Level.
6. To add disk drives, highlight disk drives in the Free Disks column and click the **>>** button to move them to the Disks in RAID column.
7. Click the **OK** button.

The RAID Volume is modified as you directed. Migration requires several minutes, depending on the type of modification taking place and the size of your disk drives.

During the modification, your RAID Volume and all of the folders on it are fully accessible.

After the Migration is completed, you must extend the file system in order to use the storage space you have added. You can extend the file system immediately or wait until later.

8. Click the **File System Management** icon.
9. In the File System Status tab, click the **Extend File System** button.

Deleting a RAID Volume



Caution

When you delete a RAID Volume, you delete all the folders in the RAID volume and all the data saved in the folders. Back up any important data before you delete a RAID Volume.



Note

You cannot delete a RAID Volume while a background activity is running, such as Migration or Rebuild. Wait until these activities are completed.


To delete a RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Delete** tab.
4. Click the option button beside the RAID Volume you want to delete.
5. Click the **OK** button.
6. In the confirmation box, type **yes** into the field provided, then click the **OK** button.

After a RAID Volume is deleted, the SmartStor reboots automatically. When the SmartStor is fully booted:

- The System Status LED turns green (right)
 - The buzzer beeps one time (if the buzzer is enabled)
7. Close your browser then restart the browser to access PASM.

System
Status LED



Viewing an External USB Drive or Memory Stick

To view a USB drive or memory stick attached to the SmartStor:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.

The USB drive or memory stick appears as a USB External Disk

3. Click the **File System Management** icon.

The USB drive or memory stick appears as a Volume called USBDISK.

You do NOT create a RAID Volume or folders with the USB drive or memory stick as you would with the disk drives installed in the SmartStor enclosure.

With the USB drive or memory stick connected to the SmartStor, create a network drive on your PC and choose the USB disk as the folder. Then you can access the USB drive or memory stick from your PC.

See “Chapter 3: Connecting to the SmartStor” on page 21 for more information.

Formatting an External USB Drive or Memory Stick

This option only appears when SmartStor does not recognize the file system on the USB drive or memory stick.



Caution

When you format a USB drive or memory stick, you delete all the data saved on it. Back up any important data before you format.

To format a USB drive or memory stick:

1. Attach the USB drive or memory stick to one of the USB ports on the back of the SmartStor.
2. In the Tree, click the **+** beside the **RAID & File System** icon.
3. Click the **File System Management** icon.
4. On the File System Status tab, highlight the USB drive.
5. From the Format File System Type dropdown menu, choose a file system:
 - **FAT 32** – Use for Windows, Linux, and Macintosh PCs, and SmartStor
 - **Ext3** – Use for UNIX and Linux PCs, and SmartStor
6. Click the **Format USB Disk** button.
7. In the confirmation box, type **yes**, then click the **OK** button.

Formatting requires several minutes, depending on the size of your USB drive or memory stick.

Managing Backups

This category includes the following topics:

- Enabling One Touch Backup (page 105)

Enabling One Touch Backup

One Touch Backup is a feature that enables you to backup specified folders from your PC to the SmartStor by pressing a button on the front of the SmartStor.

To enable One Touch Backup:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **Client Backup** icon.
3. In the One Touch Backup tab, click the **Enable** option.
4. Click the **OK** button.

To disable One Touch Backup, click the **Disable** option, then click the **OK** button.

Managing the Network Connection

This category includes the following topics:

- Viewing Network Setup Information (page 106)
- Making Network Settings (page 106)
- Working with Jumbo Frames (page 107)

Viewing Network Setup Information

To view network setup information:

1. In the Tree, click the **+** beside the **Network** icon.
2. Click the **Network Setup** icon.

The current network setup for this SmartStor displays on the Information tab:

- Computer Name
- IP Address
- Subnet Mask
- Default Gateway IP Address
- Primary Domain Name Server IP Address
- Secondary Domain Name Server IP Address

To change these settings, click the **Setup** tab.

Making Network Settings

To make network settings:

3. In the Tree, click the **+** beside the **Network** icon.
4. Click the **Network Setup** icon.
5. Click the **Setup** tab.
6. Optional. Type a name for the SmartStor in the Computer Name field.
7. Click an option button to choose an Internet Protocol option:
 - **Obtain an IP address automatically** – Choose this option to let your DHCP server make the network settings.
 - **Specify an IP address** – Choose this option if you want to make your network settings manually.

8. Optional. If you chose *Specify an IP address*, enter the following settings in the fields provided:
 - IP Address
 - Subnet Mask
 - Default Gateway IP Address
 - Primary Domain Name Server IP Address
 - Secondary Domain Name Server IP AddressSee your Network Administrator for help in making these settings.
9. Click the **OK** button to save your settings.

Working with Jumbo Frames

The term *jumbo frame* refers to a frame on a local area network that is larger than the standard 1518 byte size. SmartStor supports jumbo frames up to 7000 bytes.

On SmartStor, the frame size setting is called Maximum Transmission Unit (MTU). The default MTU or frame is 1500 bytes. This setting is appropriate for most users. See your Network Administrator before you change this setting.

To make frame size settings:

1. In the Tree, click the **+** beside the **Network** icon.
2. Click the **Network Setup** icon.
3. Click the **Jumbo Frame** tab.
4. From the MTU dropdown menu, choose the maximum MTU or frame size:
 - 1500 bytes (default)
 - 4000 bytes
 - 7000 bytes
5. Click the **OK** button to save your setting.

Making Management Settings

This category includes the following topics:

- Viewing the Event Log (page 108)
- Setting up SMTP Authentication (page 108)
- Viewing the Email Alert List (page 109)
- Adding an Email Alert Recipient (page 109)
- Deleting an Email Alert Recipient (page 109)
- Upgrading the System Firmware (page 110)
- Enabling and Disabling the Buzzer (page 110)
- Viewing UPS Status (page 110)
- Setting up a UPS (page 111)

Viewing the Event Log

The event log keeps a log of the 20 most recent events on the SmartStor. You can use this information to review your actions and to diagnose problems.

To view the Event Log:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Event Log** icon.

A list of the 20 most recent events displays on the Event Log tab.

Events are ranked in severity as Information, Warning, and Error.

Setting up SMTP Authentication

In order to set up email alerts over a network, you must enable the SMTP service, specify a SMTP server, and in most cases, supply authentication information. See your Network Administrator for help with these settings.

To set up SMTP authentication:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Mail Alert** icon.
3. Click the **Setup** tab.
4. Next to Service, click the **Enable** option button.
5. In the SMTP Server field, type the IP address or the DNS name of your SMTP server.
6. In the From field, the sender's email address that you want to appear in the alert messages.

7. Next to SMTP Authentication:
 - Click the **Yes** option button to enable authentication.
 - Click the **No** option button to disable authentication.Note that most SMTP servers require authentication.
8. If you enabled authentication, to the following:
 - In the User Name field, type the mail server account name.
 - In the Password field, type the password of the mailer server account.
9. Click the **OK** button.

Viewing the Email Alert List

The SmartStor will send alerts via email to the recipients you designate.

To view a list of Email Alert recipients:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Mail Alert** icon.

The list of recipients displays on the Mail List tab.

See “Checking Your Email Inbox” on page 124 for an example of an email alert message.

Adding an Email Alert Recipient

You can have up to 32 Email Alert recipients.

To add an Email Alert recipient:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Mail Alert** icon.
3. Click the **Add** tab.
4. In the E-Mail Address field, type the recipient's email address.
5. Click the **OK** button.

Deleting an Email Alert Recipient

To delete an Email Alert recipient:

6. In the Tree, click the **+** beside the **Management** icon.
7. Click the **Mail Alert** icon.
8. Click the **Delete** tab.
9. Click the option button beside the E-Mail Address you want to delete.
10. Click the **OK** button.
11. In the confirmation box, click the **OK** button.

Upgrading the System Firmware

See “Upgrading the Firmware” on page 147.

Enabling and Disabling the Buzzer

The SmartStor has a buzzer that sounds when the SmartStor is finished booting and when a problem is detected. The buzzer is enabled by default.

Promise recommends that you leave the buzzer enabled.

To disable the buzzer:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Buzzer** icon.
3. Click the **Disable** option button.
4. Click the **OK** button.

Click the **Enable** option button, then click the **OK** button to enable the buzzer.

Viewing UPS Status

If you have an APC Uninterruptable Power Supply (UPS) attached to the SmartStor, you can check its status in PASM.

To view UPS status:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **APC UPS** icon.

The Information tab displays the status of the UPS.

If there is no UPS connected or recognized, the Status field reports “NO UPS.”

Setting up a UPS

To set up a UPS:

1. Attach the APC UPS to one of the SmartStor's USB ports.
2. In the Tree, click the **+** beside the **Management** icon.
3. Click the **APC UPS** icon.
4. Click the **Setup** tab.

The Setup tab enables you to tell the SmartStor how and when to shutdown after a power failure.

Click the option button beside the shutdown option you want:

- Disable (the SmartStor runs until the UPS battery is depleted)
 - Shutdown when the UPS reaches a set percentage of reserve power
 - Shutdown after running on the UPS batteries for a set number of minutes
5. Optional. If you chose battery percentage, type a percentage amount in the % field.
 6. Optional. If you chose remaining runtime or running on batteries, type the number of minutes into the Mins. field.
 7. Click the **OK** button.

Managing Services

This category includes the following topics:

- Setting System Date and Time (page 112)
- Running the Network Time Protocol (page 112)
- Viewing the Results of NTP Synchronization (page 113)
- Rebooting the SmartStor (page 113)
- Shutting Down the SmartStor (page 114)
- Booting the SmartStor After a Shutdown (page 114)
- Locating the SmartStor (page 114)
- Viewing System Information (page 115)
- Viewing Enclosure Information (page 115)
- Enabling the Smart Fan (page 116)

Setting System Date and Time

1. To set the date and time on the SmartStor:
In the Tree, click the **+** beside the **System** icon.
2. Click the **Date / Time** icon.
3. Click the **Setup** tab.
4. From the dropdown menus, choose the time and date values.
5. Click the **OK** button.

Running the Network Time Protocol

You can use the Network Time Protocol (NTP) to set the system date and time on your SmartStor to synchronize itself with an external Time Server.

To run the Network Time Protocol:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Date / Time** icon.
3. Click the **Time Zone** tab.
4. From the dropdown menu, choose the time zone for your location.
5. Click the **OK** button.
6. Click the **NTP** tab.
7. In the Time Server field, type the URL of the time server you want to use.
URL *time.nist.gov* is the default.

8. Under Schedule, choose one of the options:
 - **Disable** – Disables NTP synchronization
 - **Do it at once** – Performs a synchronization when you click the OK button.
 - **Time interval by hour** – Set an hourly interval for a synchronization to happen.
 - **Daily** – Sets the time of day when the synchronization happens.
 - **Weekly** – Sets the time of day and day of the week when the synchronization happens.
9. Click the **OK** button.

Viewing the Results of NTP Synchronization

To view the results of an NTP synchronization:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Date / Time** icon.
3. Click the **NTP** tab.

The results of the latest synchronization are displayed:

- **Last Synchronization Time** – Time and date of the last synchronization
- **Last Synchronization Result** – OK means success

Rebooting the SmartStor

Normally you will only need to reboot the SmartStor is after a firmware upgrade or a plug-in installation. See “Upgrading the Firmware” on page 145. During the reboot, none of your folders will be accessible from your networked PCs.


To reboot the SmartStor:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Reboot / Shutdown** icon.
3. Click the **Reboot** option.
4. Click the **OK** button.
5. In the confirmation box, click the **OK** button.

The reboot runs automatically. When the SmartStor is fully booted:

- The system status LED turns green (right)
- The buzzer beeps one time (if the buzzer is enabled)

See “Enabling and Disabling the Buzzer” on page 110.



Shutting Down the SmartStor

The only time you need to shut down the SmartStor is to replace the disk drive cooling fan or the power supply. See “Appendix B: Maintenance” on page 145.

During and after the shutdown, none of your folders will be accessible from your networked PCs.


Using PASM

To shut down the SmartStor:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Reboot / Shutdown** icon.
3. Click the **Shutdown** option.
4. Click the **OK** button.
5. In the confirmation box, click the **OK** button.

Directly

To shut down the SmartStor, press and hold the power button for five seconds. The system status LED turns red, then goes dark (right).



Booting the SmartStor After a Shutdown

To restart the SmartStor after a shutdown, press the power button on the front of the SmartStor chassis (right).

When the SmartStor is fully booted:

- The system status LED turns green (right)
- The buzzer beeps one time (if the buzzer is enabled)

See “Enabling and Disabling the Buzzer” on page 110.


Locating the SmartStor

If your SmartStor is on a rack with other equipment and you need to locate it quickly, this function will assist you.

To locate the SmartStor:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **System Information** tab.
4. Click the **Locate** button.

The SmartStor’s buzzer beeps three times and the system status LED blinks three times (right).



Viewing System Information

To view system information:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **System Information** tab.

System Information includes:

- **Operating System** – Embedded Linux
- **Firmware Version** – Changes when you upgrade the firmware. See “Upgrading the Firmware” on page 145
- **CPU model** – MPC 8313
- **Network Adapter** – Gigabit Ethernet
- **Network Flow** – Inflow and Outflow speeds in bits per second

Viewing Enclosure Information

To view enclosure information:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **Enclosure Information** tab.

Enclosure Information includes:

- CPU temperature
- System Fan Speed
- Power Status 5V
- Power Status 12V
- Power Status 3.3V

If any values are out of specification, see “Checking Enclosure Status in PASM” on page 120.

Enabling the Smart Fan

The Smart Fan is a feature that turns off the fan to save energy and reduce noise when the fan is not needed to cool the SmartStor enclosure. The Smart Fan is enabled by default.

To enable the Smart Fan:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **Enclosure Information** tab.
4. Under Fan Control, click the **Enable** option.
5. Click the **OK** button.

Chapter 6: Technology Background

- Introduction to RAID (below)
 - Choosing a RAID Level (page 120)
 - RAID Volume Migration (page 121)
 - RAID Volume Migration (page 121)
-

Introduction to RAID

RAID (Redundant Array of Independent Disks) allows multiple disk drives to be combined together into a RAID Volume. You create a RAID Volume on your SmartStor when you perform the setup procedure, either in SmartNAVI or the PASM Setup Wizard.

The benefits of a RAID can include:

- Higher data transfer rates for increased server performance
- Increased overall storage capacity for a single Volume
- Data redundancy/fault tolerance for ensuring continuous system operation in the event of a disk drive failure

Different RAID levels use different organizational models and have varying benefits. Also see “Choosing a RAID Level” on page 120. The following outline breaks down the properties for each RAID level supported on the SmartStor:

RAID 0 – Stripe

When a RAID Volume is striped, the read and write blocks of data are interleaved between the sectors of multiple disk drives. Performance is increased, since the workload is balanced between drives or “members” that form the RAID Volume. Identical drives are recommended for performance as well as data storage efficiency.




Figure 1. RAID 0 Striping interleaves data across multiple drives

The RAID Volume’s data capacity equals the capacity of the smallest disk drive times the number of disk drives. For example, a 200 GB and a 300 GB drive will form a 400 GB RAID Volume instead of 500 GB.

If disk drives of different capacities are used, there will also be unused capacity on the larger drives.

Because RAID 0 does not offer Fault Tolerance, meaning that you cannot recover your data after a disk drive failure, Promise does not recommend a RAID 0 Volume for your SmartStor.

RAID 0 Volumes on SmartStor consist of one or two disk drives.

RAID 1 – Mirror

When a RAID Volume is mirrored, identical data is written to a pair of disk drives, while reads are performed in parallel. The reads are performed using elevator seek and load balancing techniques where the workload is distributed in the most efficient manner. Whichever drive is not busy and is positioned closer to the data will be accessed first.

With RAID 1, if one disk drive fails or has errors, the other mirrored disk drive continues to function. This is called *Fault Tolerance*. Moreover, if a spare disk drive is present, the spare drive will be used as the replacement drive and data will begin to be mirrored to it from the remaining good drive.




Figure 2. RAID 1 Mirrors identical data to two drives

The RAID Volume's data capacity equals the smaller disk drive. For example, a 300 GB disk drive and a 500 GB disk drive have a combined capacity of 300 GB in a mirrored RAID Volume.

If disk drives of different capacities are used, there will also be unused capacity on the larger drive.

RAID 1 Volumes on SmartStor consist of two disk drives.

Choosing a RAID Level

There are several issues to consider when choosing the RAID level for your Volume. The following discussion summarizes some advantages, disadvantages and applications for each choice.

RAID 0

Advantages	Disadvantages
Implements a striped disk RAID Volume, the data is broken down into blocks and each block is written to a separate disk drive I/O performance is greatly improved by spreading the I/O load across many channels and drives No parity calculation overhead is involved	Not a true RAID because it is not fault-tolerant The failure of just one drive will result in all data in an RAID Volume being lost Should not be used in mission critical environments

Recommended applications for RAID 0:

- Image Editing
- Pre-Press Applications
- Any application requiring high bandwidth

RAID 1

Advantages	Disadvantages
Simplest RAID storage subsystem design Can increase read performance by processing data requests in parallel since the same data resides on two different drives	Very high disk overhead - uses only 50% of total capacity

Recommended applications for RAID 1:

- Accounting/Financial
- Payroll
- Any application requiring very high availability

RAID Volume Migration

Migration is the process of:

- Changing the RAID level
- Adding disk drives but keeping the same RAID level

In the migration process, the existing RAID Volume is called the *Source*. The proposed RAID Volume is called the *Target*. Each target RAID Volume has certain requirements and they are different for each RAID level. You must meet all of the requirements in order to successfully migrate a RAID Volume.

In most cases, you must add one or more disk drives during the migration process. You can never reduce the number of disk drives.

While the migration is running, you can still access the folders on your RAID Volume and the data they contain.

RAID 0 to RAID 1

A single-drive RAID 0 source Volume can migrate to RAID 1 by adding a disk drive. This action reduces the Volume's capacity by one-half but adds fault tolerance.

RAID 1 to RAID 0

A RAID 1 source Volume can migrate to a RAID 0. This action doubles the Volume's capacity but loses fault tolerance.

RAID Volume Rebuilding

When a disk drive in your RAID 1 Volume fails, your data is still available and the Volume can be recovered.

The RAID 1 Volume will begin to rebuild itself automatically when you remove the failed disk drive and install a new disk drive.

A RAID 0 Volume cannot be rebuilt because of the way in which data is written to the disk drives under RAID 0. Even if there is a designated spare drive, rebuilding is not possible for RAID 0 Volumes.

Partition and Format

When you create a RAID Volume on SmartStor, the RAID Volume is automatically partitioned and formatted for you.

To use your RAID Volume, you must create Folders on the RAID Volume and assign services to those Folders according to your requirements. SmartStor provides file services for Windows, UNIX/Linux and Macintosh, so all of those PCs can access the folders on the SmartStor, even though each PC might have a different file system.

Chapter 7: Troubleshooting

- Responding to an Audible Alarm (page 123)
- Checking the System Status LED (page 124)
- Checking Disk Status LEDs (page 124)
- Replacing a Failed Disk Drive (page 124)
- Checking RAID Volume Status in PASM (page 125)
- Checking File System Status in PASM (page 127)
- Checking the Event Log in PASM (page 128)
- Checking Enclosure Status in PASM (page 131)
- Resolving Connections with SmartNAVI (page 132)
- Solving Network Connection Problems (page 133)
- Restoring the Default Password (page 134)
- Resolving a Windows Firewall Issue (page 135)

This chapter deals problems you might encounter with your SmartStor and how to resolve them. Also see “Frequently Asked Questions” on page 137.

Responding to an Audible Alarm

The SmartStor has two beep patterns

- **Single beep, not repeated** – The SmartStor is online
- **Two beeps, continuously repeated** – The SmartStor reports a problem

When you boot or reboot the SmartStor, and the buzzer is enabled, the buzzer sounds one time to indicate that the SmartStor is online.

If you hear the two-beep pattern, check the following items:

- System Status LED (see below)
- Drive Status LED (see page 124)
- RAID Volume status in PASM (see page 125)
- File System status in PASM (see page 127)
- Enclosure status in PASM (see page 131)
- Event Log in PASM (see page 128)
- Your email inbox (see page 134)

Checking the System Status LED

The SmartStor system status LED (see Figure 1.) reports the condition of the Enclosure fan and power supply:

- **Green** – Normal Enclosure function
- **Amber** – There is a problem with the fan or power supply
- **Red** – The fan, power supply, or file system has failed

If your SmartStor is configured to work with a UPS, it will continue to run after a power supply failure.


Checking Disk Status LEDs

The disk status LEDs (see Figure 1.) report the condition of the disk drives:

- **Green** – Normal disk drive function
- **Amber** – Rebuilding to this disk drive
- **Red** – Failed disk drive
- **Dark** – No disk drive is installed

See “Replacing a Failed Disk Drive” on page 124.

Figure 1. SmartStor Disk and System Status LEDs



Replacing a Failed Disk Drive

If a disk drive fails, the Disk Status LED is red. See Figure 1. If the disk drive belongs to a RAID Volume, the Volume goes Critical or Offline. See “Checking RAID Volume Status in PASM” on page 125.

Replace the failed disk drive with a new disk drive of the same or slightly greater capacity. You do not have to power down the SmartStor.

1. Open the SmartStor’s front door.
2. Pull out the drive carrier with the failed drive.
3. Remove the failed disk drive from the drive carrier.

4. Install a new disk drive into the carrier.
5. Place the carrier with the new disk drive back into the open slot in the SmartStor.

If the failed drive belonged to a RAID Volume, the RAID Volume will begin rebuilding as soon as the new drive is installed.

During the Rebuild, the Disk Status LED show amber. When the Rebuild is finished, the Disk Status LED turns green.

If the replacement drive is free, that is, not assigned to a RAID Volume or as a spare, the Disk Status LED remains dark after you install the new drive.

Checking RAID Volume Status in PASM

To view RAID Volume status:

1. Start PASM.
 - See “PASM in your Browser” on page 80.
 - Or see “PASM in SmartNAVI” on page 81.
2. In the Tree, click the + beside the **RAID & File System** icon.
3. Click the **RAID Management** icon.
 - The status is displayed in the **RAID Status** tab.

Figure 2. PASM reports a Critical RAID Volume



SmartStor Responds to a Critical RAID Volume

How the SmartStor responds to a Critical RAID Volume depends on the RAID level of your Volume and whether you have a spare drive available:

- For RAID 1, you must replace the failed disk drive. The RAID Volume will begin rebuilding itself when you install the new disk drive. See “Replacing a Failed Disk Drive” on page 124.

- RAID 0 Volumes go *offline* after a disk drive failure. A RAID 0 Volume cannot be rebuilt. All data on the Volume is lost.

Additional Details about Rebuilds

- The Rebuild takes several minutes, depending on the size of your disk drives.
- During a rebuild, you can access your folders on the SmartStor.
- When you replace the failed disk drive with a new disk drive, the new disk drive becomes a Free Drive.

Responding to an Invalid RAID Volume

The SmartStor considers a RAID Volume *invalid* when the RAID Volume was created by a different SmartStor. However, the RAID Volume itself remains functional and the data on it is safe.


This condition could happen when you:

- Move the disk drives from one SmartStor to a different SmartStor.
- Remove the disk drives in order to send your SmartStor for service.

When the SmartStor’s memory does not recognize the RAID Volume, so PASM displays the RAID Volume as invalid. See Figure 3.

Use the Recover function to validate the RAID Volume. The Recover tab is only active when an invalid RAID Volume is present and can be recovered.

Figure 3. An invalid RAID Volume in PASM



Using the Recover Function

To validate the RAID Volume:

1. In the Tree, click the + beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Recover** tab.

4. On the **Recover** tab, click the option button beside the invalid RAID Volume.
5. Click the **OK** button.

The SmartStor will reboot itself to update its configuration and recognize the RAID Volume.



Important

Running the Recover function might erase some or all of your SmartStor settings. If that condition happens, run the NAS Setup Wizard. See “Setting up the SmartStor” on page 11.

Checking File System Status in PASM

Typically the first indication of a problem with the SmartStor’s file system is when your network drive becomes unavailable.

You might also see the message, “File system contains errors. Please check.” when you click the icons under the File & Print menu.

To view File System status:

1. Start PASM.
See “PASM in your Browser” on page 80.
Or see “PASM in SmartNAVI” on page 81.
2. In the Tree, click the **+** beside the **RAID & File System** icon.
3. Click the **File System Management** icon.
4. Look for the RAID Volume  icon on the **File System Status** tab.

If the RAID Volume icon is Critical  (has a yellow !), the file system contains errors and you must rebuild the file system. See below.

Rebuilding the File System



Caution

When you rebuild a File System, you delete all the folders in the RAID volume and all the data saved in the folders.

To rebuild a File System:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **File System Management** icon.
3. In the **File System Status** tab, click the RAID Volume Critical  icon to display the **Rebuild File System** button.

4. Click the **Rebuild File System** button.
5. In the confirmation box, type **yes** into the field provided, then click the **OK** button.

Checking the Event Log in PASM

To view the Event Log in PASM:

To check Enclosure status:

1. Start PASM.
See "PASM in your Browser" on page 80.
Or see "PASM in SmartNAVI" on page 81.
2. In the Tree, click the **+** beside the **Management** icon.
3. Click the **Event Log** icon.
The Event Log displays. See Figure 4.

Figure 4. The PASM Event Log

Event Log Help		
Event Log List		
Date / Time	Level	Message
Feb 12 13:56:25	WARNING	Rebuild on array 1 10%
Feb 12 13:51:14	WARNING	Rebuild on array 1 started
Feb 12 13:51:14	WARNING	Disk 2 plugged in
Feb 12 13:49:28	WARNING	RAID status: "CRITICAL". The NS2300N (sammyz_stash) volume "VOLUME1" is not functioning correctly.
Feb 12 13:33:08	INFO	System is starting to work.
Feb 6 14:31:03	INFO	System is shutting down.
Feb 5 13:14:27	INFO	System is starting to work.
Feb 5 11:18:05	INFO	System is shutting down.
Feb 4 15:33:26	INFO	System is starting to work.
Feb 1 18:03:33	INFO	System is shutting down.
Jan 29 11:56:55	INFO	System is starting to work.
Jan 25 19:02:07	INFO	System is shutting down.
Jan 25 17:01:16	INFO	Delete volume (VOLUME1).
Jan 25 16:58:19	INFO	System is starting to work.
Jan 25 16:57:31	INFO	System is shutting down.
Jan 25 16:53:55	INFO	System is starting to work.
Jan 25 16:53:11	INFO	System is rebooting.
Jan 25 16:53:02	INFO	Delete RAID (RAID-117786).
Jan 23 13:27:32	INFO	System is starting to work.
Jan 23 13:27:31	INFO	System is shutting down.

4. Check the Event Log for reports of disk drive failure or other problems.

Responding to Events

All events are reported in the Event Log. Most events are simply reports that the SmartStor is responding to your commands.

Many events are also reported via email. The SmartStor's buzzer sounds for serious events that require your attention.

A list of event categories is shown below:

- File System (page 129)
- System (enclosure) (page 129)
- Disk Drives (page 130)
- RAID Volumes (page 130)

Reported Event	Corrective Action
File System	
File system of volume X content errors! Check the system before continuing.	The file system has a problem. Reboot the SmartStor and check file system again. If the event appears again, the file system has crashed. Rebuild the file system. See page 127.
File system capacity usage of volume X is over 90%.	Reduce the number or size of the files or expand the volume size. See "Migrating a RAID Volume" on page 102.
File system capacity usage of volume X is 100%.	
Rebuilding file system...	The file system is being rebuild by user action.
System (enclosure)	
System is starting to work.	Normal.
System is rebooting.	
System is shutting down.	
System was shut down abnormally.	The SmartStor shut down incorrectly the last time. See "Shutting Down the SmartStor" on page 114.
CPU temperature is higher than 58°C/138°F. System will shut down.	Allow the SmartStor to cool for several minutes. Then restart the SmartStor and check system temperature and fan operation. See page 131. Be sure there is adequate air circulation around the SmartStor.


Reported Event	Corrective Action
System fan speed is lower than 1800 RPM. Check the system before continuing.	Only reported when the Smart Fan is disabled. See page 116. Replace the fan. See “Contacting Technical Support” on page 140.
AC Power failure. System will shut down.	Restore the AC power. Then restart the SmartStor. See “Connecting the Power” on page 7.
Disk Drives	
Task X timeout on disk Y at LBA [address]	A LBA error. Check the disk drives. See page 124. Check the RAID Volume. See page 125. Replace the disk drive or rebuild the RAID Volume as needed.
Task X disk error on disk Y at LBA [address] with status Z	
S.M.A.R.T threshold exceeded on disk X	Check the disk drives. See page 124. Replace the failed drive. See page 124.
BSL update on disk X at LBA [address]	Bad sector on a disk drive. Check the disk drives. See page 124. Replace the disk drive if it continues to receive BSL updates.
BSL log disk X at LBA [address] cleared	Check the disk drives. See page 124.
Delete Spare Disk	Delete a spare drive. Normal.
RAID Volumes	
Create [RAID name, RAID level and X number of disk drives]	Create a RAID Volume. Normal.
Delete RAID X	Delete a RAID Volume. Normal.
Migration or Rebuilding on array X started.	RAID Volume Migration or Rebuild has started. Normal.
Migration or Rebuilding on array X at Y%.	Progress report on RAID Volume Migration or Rebuild. Normal.
Migration or Rebuilding on array X paused at Y%.	RAID Volume Migration or Rebuild was paused temporarily by user action.
Migration or Rebuilding on array X resumed at Y%.	RAID Volume Migration or Rebuild was paused and then resumed by user action.
Migration or Rebuilding on array X completed.	RAID Volume Migration or Rebuild has finished. Normal.

Reported Event	Corrective Action
Migration or Rebuilding on array X aborted at Y%	RAID Volume Migration or Rebuild was aborted (stopped) by user action.
Migration or Rebuilding on array X aborted at Y% because of error.	RAID Volume Migration or Rebuild has aborted (stopped) because of an error. Check the disk drives. See page 124. Check the RAID Volume. See page 125.
RAID status: "OFFLINE". The NS2300N X volume Y is offline.	Check the disk drives. See page 124. Replace the failed drive. See page 124. Create a new RAID Volume. See page 101.
RAID status: "CRITICAL". The NS2300N X volume Y is not functioning correctly.	Check the disk drives. See page 124. Replace the failed drive. See page 124. The RAID Volume will rebuild automatically.
RAID X had some errors. Formatting was aborted!	Check the disk drives. See page 124. Replace the failed drive. See page 124.

Checking Enclosure Status in PASM

To check Enclosure status:

1. Start PASM.
See "PASM in your Browser" on page 80.
Or see "PASM in SmartNAVI" on page 81.
2. In the Tree, click the + beside the **System** icon.
3. Click the **System Information** icon.
4. Click the **Enclosure Information** tab.

Figure 5. The Enclosure Information tab with malfunctions shown


The corrective action you take depends on the nature of the problem:

- If CPU temperature is above specification:
 - Be sure there is adequate air flow around the SmartStor.
 - Be sure the ambient temperature is below 35°C (95°F).
 - Check the fan speed.
- If the fan speed is below specification, contact Technical Support. See page 140.
- If any power status is out-of-specification, contact Technical Support. See page 140.

Resolving Connections with SmartNAVI

The SmartNAVI software is designed to detect the SmartStor on your network. If SmartNAVI does not detect your SmartStor, check the following items:

- Be sure the SmartStor is powered up and fully booted.
The Power Button and System Status LED should be green. See Figure 6.
- Be sure the SmartStor is properly connected to your network.
The Ethernet Activity LED should be green or blinking green. See Figure 6.
If the Ethernet Activity LED is dark, see “Solving Network Connection Problems” on page 133.

Figure 6. Power Button, System Status and Ethernet Activity LEDs

Note: This SmartStor is shown without the front door.

Solving Network Connection Problems

Most network connection problems are the result of poor connections.

When the SmartStor is fully booted and connected to the network, the Ethernet Activity LED indicates status and activity:

- **Green** – Network link is properly connected
- **Flashing Green** – Network Activity
- **Dark** – No Connection

See Figure 6.

If your SmartStor is connected to your network but the Ethernet Activity LED on your SmartStor is dark, check the following items:


- Verify that the switch, hub, or facility network service connection that you are using is operational.
Switches and hubs have LEDs that light when there is a connection and flash when there is activity.
Network service connections generally do not have LEDs to verify whether they actually are connected to the network. See your Network Administrator for assistance.
- Be sure the network cable is firmly attached to the SmartStor network connector at one end and to the network switch, hub, or facility network connection at the other.
- If the cable connections are good, remove the existing network cable and install a known-good network cable.

If you know your network devices are working properly and you know that your network cable is good, but the Ethernet Activity LED remains dark, see “Contacting Technical Support” on page 140.

Checking Your Email Inbox

If you enabled Mail Alert in PASM, the SmartStor will send you an email message when a problem arises. Look for a message from “root.”

Figure 7. Email message from the SmartStor.



See “Adding an Email Alert Recipient” on page 109 for more information about email alerts.

Restoring the Default Password


Normally, you change your password in PASM. See “Changing the Administrator’s Password” on page 85.

If you changed the password and then forgot the new password, you can reset the SmartStor to the default password: **admin**. Use a straightened paper clip or the tip of a ball-point pen as a reset tool.

To reset the Administrator’s password:

1. Verify that the SmartStor is fully booted.
2. Insert your reset tool into the reset button hole on the back of the SmartStor. See Figure 8.
3. Press and hold the reset button for eight seconds, until the System Status LED flashes three times.

The Administrator’s password is now reset to **admin**.

Figure 8. Reset button and System Status LED

Resolving a Windows Firewall Issue

If you are running a personal firewall on your Windows PC, the firewall might prevent you from accessing the SmartStor over your network.


Follow this procedure to add an exception for the SmartStor:

1. From the Windows Start menu, choose *Settings*, then *Network Connections*.
The Network Connections window opens.
2. Right-click **Local Area Connection** and choose *Properties* from the popup menu.
The local Area Connection properties dialog box opens.
3. Click the **Advanced** tab.
4. Click the **Settings** button.
The Windows Firewall dialog box opens.
5. Click the **Advanced** tab.
6. Under Network Connection Setting, click the **Settings** button.
The Advanced Settings dialog box opens.
7. Click the **Add** button.
The Service Settings dialog box opens.
8. In the Description of service field, type **Promise NAS utility**.
9. In the Name or IP address field, type the IP address of the SmartStor.

See “Finding the SmartStor’s IP Address” on page 15.

10. In the External Port field, type **49152**.
11. Click the **UDP** option button.
12. In the Internal Port field, type **49152**.
13. Click the **OK** button.

Figure 9. Windows Firewall Advanced Service Settings



14. Click the **OK** buttons in the Advanced Settings, Windows Firewall, and Local Area Connection Properties dialog boxes.

Chapter 8: Support

- Frequently Asked Questions (below)
 - Contacting Technical Support (page 140)
 - Limited Warranty (page 143)
 - Returning Product For Repair (page 145)
-

Frequently Asked Questions

Also see “Chapter 7: Troubleshooting” on page 123.

The SmartStor worked OK until I turned it off. When I turned it on again, my Windows network drive connection no longer works.

When you powered up the SmartStor, the DHCP server assigned a different IP address to the SmartStor. Here are two possible solutions:

- You may be able to reset the SmartStor’s IP address manually. See “Changing Network Settings” on page 69 or “Making Network Settings” on page 106.

Note that changing the SmartStor’s IP address may cause an IP address conflict on your network. Check with your Network Administrator before taking this action.

- If you cannot restore the previous IP address, you must create new network drives and printer connections. See “Chapter 3: Connecting to the SmartStor” on page 19.

When I start Windows, a message displays that says, “Could not reconnect all network drives.”

The SmartStor reconnects to your PC shortly after Windows starts. In most cases, the SmartStor network drives will be available by the time you click them.

SmartNAVI cannot access the SmartStor over the network.

If you are running a personal firewall on your Windows PC, the firewall might prevent you from accessing folders on the SmartStor. You must do one of the following actions:

- Disable the firewall
- Add an exception for the SmartStor

See “Resolving a Windows Firewall Issue” on page 135.

I tried to connect my SmartStor as a network drive using SmartSYNC, but Windows displayed an error message.

There might be an IP address conflict between the SmartStor and another device on your network. See your Network Administrator for assistance.

I cannot log into the SmartStor with through the AD Domain.

Be sure you use a “domain name\user name” when you log into the SmartStor using SMB, FTP, or AFP. You must use the “\” character.

Many FTP clients do not support a space in the domain name or user name.

Also, the SmartStor does not support a user home directory.

How does the SmartStor integrate into an NIS Domain?

If the NIS domain account or group name is the same as the SmartStor, the SmartStor will apply them to its account or group.

If the SmartStor joins a NIS Domain, joining only affects the NFS service and Quota settings. The other services are not affected.

How are non-ASCII folder file names displayed?

The SmartStor supports Unicode, so you can use non-ASCII characters in your folder names. Windows 98 and ME do not support Unicode, so they cannot display your folder names properly. But you can still access your folders.

I tried to copy a Windows shortcut to my network drive, but an error message says there is not enough free disk space.

Normally, you can copy a Windows shortcut to a network drive. However, if the network drive is a USB drive or memory stick with FAT32 file format, the SmartStor might not recognize the shortcut and prevent you from copying it.

If this situation occurs, choose a different folder in which to copy the shortcut.

Does SmartStor support a USB drive or memory stick with FAT16 file format?

No. If you attach the FAT16 USB drive or memory stick to SmartStor, you can see the files on it. But if you attempt to copy files to the drive or memory stick, Windows might display a *disk full* message.

How do I remove a USB drive or memory stick from the SmartStor?

Be sure that no files on the USB drive or memory stick are still open. Then unplug the USB drive or memory stick from the SmartStor. The SmartStor automatically unmounts the USB drive or memory stick.

Can I do a One Touch Backup or a regular Backup on a protected folder or file on my Windows PC?

No. Windows does not allow SmartSYNC to access protected folders and files. If you want to perform a backup, you must first disable protection on your folders and files.

Which FTP clients are compatible with the SmartStor's FTP server?

Promise recommends FTP clients that support Unicode, such as Filezilla or Smart FTP for Windows, Filezilla for Linux, and Transmit v3.5.5 for Macintosh.

If your FTP client does not support Unicode, you have two choices:

- Use only ASCII characters to name your shared folders.
- Set your SmartStor for double-byte character encoding. See page 93.

Can I move the disk drives from one SmartStor to a different SmartStor?

Yes. However, to access the RAID Volume on the new SmartStor, you must run the Recover function. When SmartStor's memory does not match the RAID Volume on the disk drives, the RAID Volume is considered *invalid* and the Recover function becomes available. See "Responding to an Invalid RAID Volume" on page 126.

I set up email alert recipients but they never receive any messages.

In most cases, you must setup SMTP authentication in order for your alert messages to pass your SMTP server. See "Setting up SMTP Authentication" on page 108.

Can SmartStor handle jumbo frames?

Yes. But you must set the maximum frame size in PASM. See "Working with Jumbo Frames" on page 107.

I tried to create a share folder called "Admin" but the PASM software would not let me.

The Admin name is a reserved folder name. Choose another folder name.

I created a share folder and gave it the same name as a local user. This action caused a conflict.

The system does not check share folder names against user names, therefore it is possible to create two folders with the same name. If this happens, delete the share folder, so that only the user's home folder remains.

Contacting Technical Support

Promise Technical Support provides several support options for Promise users to access information and updates. We encourage you to use one of our electronic services, which provide product information updates for the most efficient service and support.

If you decide to contact us, please have the following information available:

- Product model and serial number
- BIOS, firmware, and driver version numbers
- A description of the problem / situation
- System configuration information, including: motherboard and CPU type, hard drive model(s), SAS/SATA/ATA/ATAPI drives & devices, and other controllers.

Technical Support Services

Promise Online™ Web Site	http://www.promise.com/support/support_eng.asp (technical documents, drivers, utilities, etc.)
--------------------------	--

United States

E-mail Support	e-Support On-Line
Fax Support	(408) 228-1100 Attn: Technical Support
Phone Support	(408) 228-1400 option 4
If you wish to write us for support:	Promise Technology, Inc. 580 Cottonwood Drive Milpitas, CA 95035, USA

Europe, Africa, Middle East

E-mail Support	e-Support On-Line
Fax Support	+31 (0) 40 256 9463 Attn: Technical Support
Phone Support	+31 (0) 40 235 2600
If you wish to write us for support:	Promise Technology Europe B.V. Science Park Eindhoven 5542 5692 EL Son, The Netherlands

Germany

E-mail Support	e-Support On-Line
Fax Technical Support	+49 (0) 2 31 56 76 48 - 29 Attn: Technical Support
Phone Technical Support	+49 (0) 2 31 56 76 48 - 10
If you wish to write us for support:	Promise Technology Germany Europaplatz 9 44269 Dortmund, Germany

Italy

E-mail Support	e-Support On-Line
Fax Support	0039 06 367 12400 Attn: Technical Support
Phone Support	0039 06 367 12626
If you wish to write us for support:	Promise Technology Italy Piazza del Popolo 18 00187 Roma, Italia

Taiwan

E-mail Support	e-Support On-Line
Fax Support	+886 3 578 2390 Attn: Technical Support
Phone Support	+886 3 578 2395 (ext. 8822, 8823)
If you wish to write us for support:	Promise Technology, Inc. 2F, No. 30, Industry E. Rd. IX Science-based Industrial Park Hsin-Chu 30075, Taiwan (R.O.C.)

China

E-mail Support	e-Support On-Line
Fax Support	+86-10-8857-8015 Attn: Technical Support
Phone Support	+86-10-8857-8085/8095
If you wish to write us for support:	Promise Technology China Room 1205, Tower C Webok Time Center, No.17 South Zhong Guan Cun Street Hai Dian District, Beijing 100081, China

Limited Warranty

Promise Technology, Inc. (“Promise”) warrants that for three (3) years from the time of the delivery of the product to the original end user:

- a) the product will conform to Promise’s specifications;
- b) the product will be free from defects in material and workmanship under normal use and service.

This warranty:

- a) applies only to products which are new and in cartons on the date of purchase;
- b) is not transferable;
- c) is valid only when accompanied by a copy of the original purchase invoice.
- d) Is not valid on spare parts, fans, and power supplies

This warranty shall not apply to defects resulting from:

- a) improper or inadequate maintenance, or unauthorized modification(s), performed by the end user;
- b) operation outside the environmental specifications for the product;
- c) accident, misuse, negligence, misapplication, abuse, natural or personal disaster, or maintenance by anyone other than a Promise or a Promise-authorized service center.

Disclaimer of other warranties

This warranty covers only parts and labor, and excludes coverage on software items as expressly set above.

Except as expressly set forth above, Promise **DISCLAIMS** any warranties, expressed or implied, by statute or otherwise, regarding the product, including, without limitation, any warranties for fitness for any purpose, quality, merchantability, non-infringement, or otherwise. Promise makes no warranty or representation concerning the suitability of any product for use with any other item. You assume full responsibility for selecting products and for ensuring that the products selected are compatible and appropriate for use with other goods with which they will be used.

Promise **DOES NOT WARRANT** that any product is free from errors or that it will interface without problems with your computer system. It is your responsibility to back up or otherwise save important data before installing any product and continue to back up your important data regularly.

No other document, statement or representation may be relied on to vary the terms of this limited warranty.

Promise's sole responsibility with respect to any product is to do one of the following:

- a) replace the product with a conforming unit of the same or superior product;
- b) repair the product.

Promise shall not be liable for the cost of procuring substitute goods, services, lost profits, unrealized savings, equipment damage, costs of recovering, reprogramming, or reproducing of programs or data stored in or used with the products, or for any other general, special, consequential, indirect, incidental, or punitive damages, whether in contract, tort, or otherwise, notwithstanding the failure of the essential purpose of the foregoing remedy and regardless of whether Promise has been advised of the possibility of such damages. Promise is not an insurer. If you desire insurance against such damage, you must obtain insurance from another party.

Some states do not allow the exclusion or limitation of incidental or consequential damages for consumer products, so the above limitation may not apply to you.

This warranty gives specific legal rights, and you may also have other rights that vary from state to state. This limited warranty is governed by the State of California.

Your Responsibilities

You are responsible for determining whether the product is appropriate for your use and will interface with your equipment without malfunction or damage. You are also responsible for backing up your data before installing any product and for regularly backing up your data after installing the product. Promise is not liable for any damage to equipment or data loss resulting from the use of any product.

Returning Product For Repair

If you suspect a product is not working properly, or if you have any questions about your product, contact our Technical Support Staff through one of our Technical Services, making sure to provide the following information:

- Product model and serial number (required)
- Return shipping address
- Daytime phone number
- Description of the problem
- Copy of the original purchase invoice

The technician will assist you in determining whether the product requires repair. If the product needs repair, the Technical Support Department will issue an RMA (Return Merchandise Authorization) number.



Important

Obtain an RMA number from Technical Support *before* you return the product and write the RMA number on the label. The RMA number is essential for tracking your product and providing the proper service.

Return **ONLY** the specific product covered by the warranty (do not ship cables, manuals, diskettes, etc.), with a copy of your proof of purchase to:

USA and Canada: Promise Technology, Inc.
 Customer Service Dept.
 Attn.: RMA # _____
 47654 Kato Road
 Fremont, CA 94538

Other Countries: Return the product to your dealer
 or retailer.
 Contact them for instructions
 before shipping the product.

You must follow the packaging guidelines for returning products:

- Use the original shipping carton and packaging
- Include a summary of the product's problem(s)
- Write an attention line on the box with the RMA number
- Include a copy of proof of purchase

You are responsible for the cost of insurance and shipment of the product to Promise. Note that damage incurred due to improper transport or packaging is not covered under the Limited Warranty.

When repairing returned product(s), Promise may replace defective parts with new or reconditioned parts, or replace the entire unit with a new or reconditioned unit. In the event of a replacement, the replacement unit will be under warranty for the remainder of the original warranty term from purchase date, or 30 days, whichever is longer.

Promise will pay for standard return shipping charges only. You will be required to pay for any additional shipping options (such as express shipping).

Appendix A: Maintenance

- Upgrading the Firmware (below)
 - Upgrading the Software (page 148)
 - Connection Problems After Restart (page 149)
-

Upgrading the Firmware

Follow this procedure to upgrade the firmware on your SmartStor.

Downloading the Firmware Upgrade File

To download the upgrade file:

1. Point your browser to http://www.promise.com/support/support_eng.asp.
2. Download the NS2300N firmware upgrade file to your PC.
3. Copy the firmware upgrade file from your PC to a folder on the SmartStor.

Installing the Firmware Upgrade File

1. Start the PASM interface.
2. In the Tree, click the + beside the **Management** icon.
3. Click the **System Upgrade** icon.
4. Click the **Firmware Upgrade** tab.
5. From the Volume dropdown menu, choose the Volume that has the folder with the firmware image file.
6. From the Folder dropdown menu, choose the Folder that contains the firmware upgrade file.
7. In the File Name field, type the name of the firmware upgrade file.
Or highlight the file and copy the name, then paste the name into the field.
8. Click the **OK** button to begin the upgrade.

The upgrade takes about two to three minutes.



Warning

Do not disconnect the power or shut down the SmartStor while the upgrade is running!

When the installation is done, the SmartStor reboots automatically. When the SmartStor beeps once, it is ready for use.

Upgrading the Software

Follow this procedure to upgrade the SmartNAVII configuration software on your PC. The software upgrade file automatically overwrites the existing SmartNAVI installation on your PC.



Important

To configure the SmartStor, you must install the software onto a PC running Windows Vista, 2003 Server, XP Professional, or 2000.

Downloading the Software Upgrade File

To download the upgrade file:

1. Point your browser to http://www.promise.com/support/support_eng.asp.
2. Download the NS2300N software upgrade file to your PC.

Installing the Software Upgrade File

1. Double-click the **NAS Utility Installer** icon.
The Choose Setup Language dialog box appears.
2. Choose your language from the dropdown menu, then click the **OK** button.
3. On the upgrade notice message, click the **Yes** button to continue.
4. On the Resuming screen, click the **Next** button to continue.
5. On the Completed screen, click the **Finish** button to exit the installer.
This action completes the software upgrade.

Connection Problems After Restart

If your SmartStor's network settings were set to *Obtain an IP address automatically*, your DHCP server might assign a different IP address to the SmartStor when you restart the SmartStor after it was shutdown for repairs.

This condition does not apply if you assigned your SmartStor's IP address manually.

If you experience network drive or printer connection failures, check the SmartStor's current IP address. See "Finding the SmartStor's IP Address" on page 15. If the SmartStor's IP address has changed, your previous network drives and printer connections will no longer work.

Here are two possible solutions:

- You may be able to reset the SmartStor's IP address manually. See "Changing Network Settings" on page 69 or "Making Network Settings" on page 106.

Note that changing the SmartStor's IP address may cause an IP address conflict on your network. Check with your Network Administrator before taking this action.

- If you cannot restore the previous IP address, you must create new network drives and printer connections. See "Chapter 3: Connecting to the SmartStor" on page 19.

Appendix B: Important Information

GNU General Public License

This product includes copyrighted third-party software licensed under the terms of the GNU General Public License. Please see the GNU General Public License (“GPL”) for the exact terms and conditions of this license at www.gnu.org.

The GPL source code incorporated into the product is available for free download at our web site www.promise.com/support/download/download_eng.asp.

Subject to GPL, you may re-use, re-distribute and modify the GPL source code. Note that with respect solely to the GPL Software, no warranty is provided, we do not offer direct support for the distribution.

Battery



Caution

Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to the instructions.

Index

A

- about this manual 1
- action status, RAID Volume 100
- AD domain 90, 138
- add
 - email alert recipient 109
 - folder 84
 - plug-ins in PASM 94
 - plug-ins in SmartNAVI 71
 - spare drive 102
 - user 83
- add member to group
 - PASM 87
 - SmartNAVI 53
- Add Printer Wizard 32
- Advanced Setup 12
- APC UPS 111
- architecture, SmartStor 2
- audible alarm 123
- Authentication dialog box 25

B

- background activity, RAID Volume 100
- backup
 - change schedule 60
 - clear event log 63
 - delete schedule 61
 - immediate 58
 - save event log 62
 - scheduling 59
 - software list 4
 - view event log 62
 - view schedules 60
- backup files, restore 61
- Bit Torrent server plug-in 71, 94
- boot SmartStor after shutdown 114
- booting the SmartStor 7
- browser support 4, 15

- BT server plug-in 71, 94
- buttons
 - Extend File System 102
 - power 6, 132
 - reset 135

- buzzer
 - enable/disable 110
 - one beep 7
 - patterns 123

C

- cable, network 133
- clear backup event log 63
- client OS support 4, 5, 148
- close
 - PASM 82
 - SmartNAVI 49
- computer name 13
- connections
 - failed after restart 137, 149
 - network 7, 133
 - resolving 132
 - USB printer 29
- connectors
 - network 6, 133
 - power 6
 - RJ45 6
 - USB 6, 37
- cooling fan 6
- CPU temperature 115, 132
- create group
 - PASM 87
 - SmartNAVI 52
- create network drive 66
- create RAID volume
 - PASM 101
 - SmartNAVI 55
- critical RAID Volume 125

D

- date and time 13, 112
- DCHP server 83
- default gateway 83, 107
- default NAS 70
- default user, SmartNAVI 51
- delete
 - email alert recipient 109
 - group in PASM 88
 - group in SmartNAVI 54
 - RAID Volume 103
 - user in PASM 86
 - user in SmartNAVI 52
- device name 13
- DHCP server 13, 106
- disconnect network drive 66
- disconnect USB drive 40
- disk drive
 - assign to RAID Volume 84
 - assign to RAID volume 7
 - events 130
 - move to a different SmartStor 126
 - replace 124
- disk drive information
 - PASM 101
 - SmartNAVI 56
- disk status LED 124
- DLNA server plug-in 71, 94
- DNS
 - IP address 13
 - name in SMTP server 108
 - server 83, 107
- domain
 - AD domain name 90
 - controller 90
- downloads
 - add link 75
 - download list 76
 - downloaded list 77
 - open/delete file 77

- downloads, cont.
 - pause/resume 76
 - remove link 76
- drive mapping 13

E

- email alert list, view 109
- Email notification 134
- enable
 - One Touch Backup 105
 - Smart Fan 116
- enclosure
 - events 129
 - status 131
- error message
 - network drive 138
 - not enough free disk space 138
- ESD warning 5
- Ethernet activity LED 132, 133
- Ethernet hub or switch 7
- event log 128
- event log, view
 - PASM 108
 - SmartNAVI 71
- events
 - disk drive 130
 - enclosure 129
 - file system 129
 - RAID Volume 130
 - response to 129
 - system 129
- expand RAID volume
 - PASM 102
 - SmartNAVI 55
- export access list, UNIX/Linux PC 92
- Ext3 file format 37

F

- fan
 - cooling 6
 - speed 115, 132
- FAT16 file format 138
- FAT32 file format 37, 138
- file protocol support 3
- file system
 - events 129
 - rebuilding 127
 - status 127
- finding SmartStor's IP address 15
- firewall, Windows 135
- firmware, updating 147
- folder
 - add 84
 - FTP sharing 99
 - names 138
 - services 96
 - UNIX/Linux sharing 98
 - view 96
 - Windows sharing 98
- formatting
 - memory stick 104
 - RAID Volume 101
 - USB drive 104
- free disks 101
- FTP
 - access setup 93
 - client encoding 93
 - clients 138, 139
 - sharing setup 99

G

- gateway IP address 13
- GNU General Public License 151
- group list
 - PASM 86
 - SmartNAVI 53

H

- hub, network 133

I

- icon
 - SmartNAVI 11, 15
 - SmartNAVI installer 8
- information, SmartNAVI 48
- installing SmartNAVI 8
- internal port in Windows 136
- invalid RAID Volume 126, 139
- IP address
 - finding 15
 - obtain from DHCP server 13, 106
 - setting 13, 83, 107
 - SMTP server 108
 - UNIX/Linux PC 23, 92, 98
- iTunes server plug-in 71, 94

J

- jumbo frames 107, 139

L

- language
 - PASM 82
 - SmartNAVI 11, 47
- LEDs
 - disk activity 6
 - disk status 6, 124
 - Ethernet activity 6, 132, 133
 - system status 6, 7, 103, 113, 114, 124, 132, 134

Linux

- export access list 92
- setup access 91
- setup network drive 22
- setup printing 32
- sharing setup 98

M

Macintosh

- setup access 92
- setup network drive 26
- setup printing 35

mail alerts 134

Main Window, open 46

Map Network Drive 21

maximum transmission unit (MTU) 107

memory stick

- format 138
- formatting 104
- view 104

migrate RAID volume 102

mirror RAID 119, 120

modify folder services 96

mount share folder 66

MSN Window, open 46

My Computer, network drive 14

My Network Places 19

N

NAS system name 13

NAS Utility Installer 148

NAS, default 70

network

- connecting to 7
- connection problems 133

network drive

- could not reconnect all 137
- create 66
- disconnect 66
- error message 138
- in My Computer 14
- letter 13

network drive setup

- Linux 22
- Macintosh 26
- UNIX 22

network drive setup, cont.

Windows 19

network information, view 106

Network Servers 24

network settings

PASM 106

SmartNAVI 69

Network Time Protocol (NTP) 112

NIS domain 91, 138

non-ASCII characters in folder name 138

not enough free disk space 138

NTP synchronization, view 113

O

One Click Setup 12

One Touch Backup, enable 105

open

Main Window 46

MSN Window 46

PASM 79

SmartNAVI 45

OS, client supported 4, 5, 148

P

partition and format 122

PASM

add member to group 87

add plug-ins 94

add share folder 97

add user 85

browser support 15

change password 85, 86

connect to 79

create group 87

create RAID volume 101

delete group 88

delete share folder 97

delete user 86

disk drive information 101

-
- PASM, cont.
 - enable/disable plug-ins 95
 - event log 128
 - expand RAID volume 102
 - group list 86
 - in browser 16, 80
 - language 82
 - locate SmartStor 114
 - log out 82
 - login 16, 17
 - migrate RAID volume 102
 - navigating the interface 82
 - network settings 106
 - RAID volume status 100
 - remove group member 87
 - set quota 88
 - Setup Wizard 83
 - through SmartNAVI 17, 47, 81
 - user list 85
 - view event log 108
 - view plug-in list 95
 - view quota 88
 - password
 - administrator's 83
 - NS4300N 36
 - PASM 80, 81, 85, 86
 - restore default 134
 - SmartNAVI 12, 51
 - SmartStor 25, 27, 30, 33
 - SMTP server 109
 - permissions
 - share folders 65
 - Windows 91
 - personal firewall 137
 - Plug-ins
 - add in PASM 94
 - add in SmartNAVI 71
 - enable/disable 73, 95
 - list 72, 95
 - power adapter 7
 - power button 6, 132
 - power status 115
 - print server, setup 30, 94
 - printer, name in Linux 33
 - printing
 - Macintosh 35
 - Windows 30
 - protected folders and files 139
 - protocols supported 2
 - Public folder 13, 20, 24
- R**
- RAID level 84, 100, 101
 - choosing 120
 - RAID 0 118, 120
 - RAID 1 119, 120
 - RAID Volume 84, 96, 97
 - automatic rebuilding 121
 - change RAID level 121
 - critical 125
 - delete 103
 - disk drives 7
 - events 130
 - formatting 101
 - invalid 126, 139
 - Maximum Capacity or Data Protection 13
 - migrate 121
 - partition and format 122
 - RAID 0 or RAID 1 13
 - rebuild 126
 - recover 126, 139
 - status 125
 - RAID volume status
 - PASM 100
 - SmartNAVI 56
 - RAID, introduction to 117
 - reboot SmartStor 113
 - rebuild
 - file system 127
 - RAID Volume 126
-

- recipient, email alert 139
 - add 109
 - delete 109
- recover RAID volume 126, 139
- recreate RAID volume in SmartNAVI 57
- remove group member
 - PASM 87
 - SmartNAVI 53
- replacing a disk drive 124
- resolving connections 132
- restore backup files 61
- RJ45 connector 7

S

- save backup event log 62
- schedule a backup 59
- scheduled backup
 - change 60
 - delete 61
- screws, counter-sink 7
- service
 - FTP 84
 - Macintosh 84
 - UNIX/Linux 84
- set quota 88
- setup
 - FTP access 93
 - Linux printing 32
 - Macintosh access 92
 - Macintosh printing 35
 - print server 30
 - print server access 94
 - UNIX/Linux access 91
 - UPS 111
 - Windows access 90
 - Windows printing 30
- Setup Wizard in PASM 83
- Setup, one-click or advanced 12
- share folder
 - list 65

- share folder, cont.
 - mount 66
 - permissions 65
 - un-mount 66
- share folder, add
 - PASM 97
 - SmartNAVI 64
- share folder, delete
 - PASM 97
 - SmartNAVI 65
- shut down SmartStor 18
- Smart Fan, enable 116
- SmartNAVI
 - add download link 75
 - add member to group 53
 - add plug-ins 71
 - add share folder 64
 - add user 50
 - cannot access SmartStor 137
 - change password 51
 - close 49
 - create group 52
 - create RAID volume 55
 - default user 51
 - delete group 54
 - delete share folder 65
 - delete user 52
 - disk drive information 56
 - download list 76
 - downloaded list 77
 - enable/disable plug-ins 73
 - expand RAID volume 55
 - group list 53
 - icon 11, 15
 - information 48
 - installer icon 8
 - installing 8
 - language 47
 - language setting 11
 - locate SmartStor 70
 - network settings 69

- SmartNAVI, cont.
 - open from desktop 45
 - open/delete downloaded file 77
 - pause/resume download 76
 - RAID volume status 56
 - recreate RAID volume 57
 - remove download link 76
 - remove group member 53
 - setting up SmartStor 11
 - updating 148
 - user list 52
 - user name and password 12
 - view event log 71
 - view plug-in list 72
- SmartStor
 - boot after shutdown 114
 - booting 7
 - cannot connect after restart 137
 - enclosure info 115
 - locating with PASM 114
 - locating with SmartNAVI 70
 - plug-ins 71, 94
 - reboot 113
 - setting up with PASM 83
 - setting up with SmartNAVI 11
 - shut down 18, 114
 - shutting down 18
 - view system info 115
- SMTP authentication 108, 139
- spare drive, add 102
- specifications 3
- status
 - disk drives 124
 - enclosure 131
 - file system 127
 - RAID Volume 125
 - SmartStor 124
 - system 124
 - UPS 110
 - stripe RAID 118, 120
 - subnet mask 13, 83, 107
 - switch, network 133
 - system events 129
 - system status LED 7, 103, 113, 114, 124, 132, 134
- T**
 - temperature, CPU 132
 - time and date 13
 - timezone 13
- U**
 - UDP option in Windows 136
 - Unicode support 138, 139
 - UNIX
 - export access list 92
 - setup access 91
 - setup network drive 22
 - sharing setup 98
 - un-mount share folder 66
 - updating firmware 147
 - updating SmartNAVI 148
 - UPnP protocol 71, 94
 - UPS 124
 - setup 111
 - view 110
 - USB drive
 - connect 37
 - disconnect 40
 - file formats 37
 - formatting 104
 - RAID Volume on 101
 - view 104
 - Windows shortcuts 138
 - USB printer, connecting 29
 - USBDISK 37, 39, 104
 - user list
 - PASM 85
 - SmartNAVI 52

user name
 NS4300N 36
 PASM 80, 81
 SmartNAVI 12
 SmartStor 25, 27, 30, 33

user, add
 PASM 85
 SmartNAVI 50
 through Setup Wizard 83

V

view
 backup event log 62
 backup schedules 60
 download list 76
 downloaded list 77
 email alert list 109
 enclosure info 115
 event log 71, 108
 folders 96
 memory stick 104

view, cont.
 network information 106
 NTP synchronization 113
 plug-in list 72, 95
 quota 88
 share folder list 65
 system info 115
 UPS status 110
 USB drive 104

W

Windows
 AD domain 90
 firewall issue 135
 setup access 90
 setup network drive 19
 setup printing 30
 setup sharing 98
 workgroup 91